



User Guide

R2000

Industrial Dual SIM Cellular VPN Router
2 Eth + 2 SIM



robustOS

Guangzhou Robustel Co., Ltd.
www.robustel.com


About This Document

This document provides hardware and software information of the Robustel R2000 Router, including introduction, installation, configuration and operation.

Copyright©2020 Guangzhou Robustel Co., Ltd..

All rights reserved.

Trademarks and Permissions

robustel , robustOS are trademarks of Guangzhou Robustel Co., Ltd.. All other trademarks and trade names mentioned in this document are the property of their respective owners.

Disclaimer

No part of this document may be reproduced in any form without the written permission of the copyright owner. The contents of this document are subject to change without notice due to continued progress in methodology, design and manufacturing. Robustel shall have no liability for any error or damage of any kind resulting from the inappropriate use of this document.

Technical Support

Tel: +86-20-82321505

Email: support@robustel.com

Web: www.robustel.com

Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the router is used in a normal manner with a well-constructed network, the router should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Robustel accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the router, or for failure of the router to transmit or receive such data.

Safety Precautions

General

- The router generates radio frequency (RF) power. When using the router, care must be taken on safety issues related to RF interference as well as regulations of RF equipment.
- Do not use your router in aircraft, hospitals, petrol stations or in places where using cellular products is prohibited.
- Be sure that the router will not be interfering with nearby equipment. For example: pacemakers or medical equipment. The antenna of the router should be away from computers, office equipment, home appliance, etc.
- An external antenna must be connected to the router for proper operation. Only uses approved antenna with the router. Please contact authorized distributor on finding an approved antenna.
- Always keep the antenna with minimum safety distance of 20 cm or more from human body. Do not put the antenna inside metallic box, containers, etc.
- RF exposure statements
 1. For mobile devices without co-location (the transmitting antenna is installed or located more than 20cm away from the body of user and nearby person)
- FCC RF Radiation Exposure Statement
 1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
 2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and human body.

Note: Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. Router may be used at this time.

Using the Router in Vehicle

- Check for any regulation or law authorizing the use of cellular devices in vehicle in your country before installing the router.
- The driver or operator of any vehicle should not operate the router while driving.
- Install the router by qualified personnel. Consult your vehicle distributor for any possible interference of electronic parts by the router.
- The router should be connected to the vehicle's supply system by using a fuse-protected terminal in the vehicle's fuse box.
- Be careful when the router is powered by the vehicle's main battery. The battery may be drained after extended period.

Protecting Your Router

To ensure error-free usage, please install and operate your router with care. Do remember the following:

- Do not expose the router to extreme conditions such as high humidity / rain, high temperature, direct sunlight, caustic / harsh chemicals, dust, or water.
- Do not try to disassemble or modify the router. There is no user serviceable part inside and the warranty would be void.
- Do not drop, hit or shake the router. Do not use the router under extreme vibrating conditions.
- Do not pull the antenna or power supply cable. Attach/detach by holding the connector.
- Connect the router only according to the instruction manual. Failure to do it will void the warranty.
- In case of problem, please contact authorized distributor.

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Regulatory and Type Approval Information

Table 1: Directives

| | | |
|------------|---|---|
| 2011/65/EU | <p>The European RoHS2.0 2011/65/EU Directive was issued by the European parliament and the European Council on 1 July 2011 on the restriction of the use of certain Hazardous substances in electrical and electronic equipment.</p> <p>On June 4, 2015, the Official Journal of the European Union published the RoHS2.0 Amendment Directive (EU)</p> <p>In 2015/863, four phthalates (DEHP, BBP, DBP, DIBP) were officially included in the list of restricted substances in Appendix II of RoHS 2.0 (2011/65/EU).</p> <p>From July 22, 2019, all electronic and electrical products exported to Europe (except medical and monitoring equipment) must meet this restriction; from July 22, 2021, medical equipment and monitoring equipment will also be included in the scope of control.</p> |  |
| 2012/19/EU | <p>The European WEEE 2012/19/EU Directive was issued by the European parliament and the European Council on 24 July 2012 on waste electrical and electronic equipment.</p> |  |
| 2013/56/EU | <p>The European 2013/56/EU Directive is a battery Directive which published in the EU official gazette on 10 December 2013. The button battery used in this product conforms to the standard of 2013/56/EU directive.</p> | |

Table 3: Toxic or Hazardous Substances or Elements with Defined Concentration Limits

| Name of the Part | Hazardous Substances | | | | | | | | | |
|--|----------------------|------|------|----------|-------|--------|--------|-------|-------|--------|
| | (Pb) | (Hg) | (Cd) | (Cr(VI)) | (PBB) | (PBDE) | (DEHP) | (BBP) | (DBP) | (DIBP) |
| Metal parts | o | o | o | o | - | - | - | - | - | - |
| Circuit modules | o | o | o | o | o | o | o | o | o | o |
| Cables and cable assemblies | o | o | o | o | o | o | o | o | o | o |
| Plastic and polymeric parts | o | o | o | o | o | o | o | o | o | o |
| <p>o: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in RoHS2.0.</p> <p>X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials for this part <i>might exceed</i> the limit requirement in RoHS2.0.</p> <p>-: Indicates that it does not contain the toxic or hazardous substance.</p> | | | | | | | | | | |

Document History

Updates between document versions are cumulative. Therefore, the latest document version contains all updates made to previous versions.

| Date | Firmware Version | Document Version | Change Description |
|---------------|------------------|------------------|--|
| 24 Aug., 2016 | 1.2.2 | V2.0.0 | Initial release |
| 31 Aug., 2016 | 1.2.2 | V2.0.1 | <ul style="list-style-type: none"> Modified the frequency range of FDD LTE and TDD LTE Modified the EMC details Modified the Tel & Fax No. |
| 8 Oct., 2016 | 1.2.2 | V2.0.2 | Updated frequency band info in Chapter 1.5 Other minor changes |
| 11 Nov., 2016 | 1.2.2 | V2.0.3 | Updated section about 2.9 Power Supply |
| 18 Nov., 2016 | 1.2.2 | v.2.0.4 | Updated information about input voltage |
| 29 Nov., 2016 | 1.2.2 | v.2.0.5 | Updated section about 1.5 Selection and Ordering Data |
| 19 Jan., 2017 | 1.2.2 | v.2.0.6 | <ul style="list-style-type: none"> Changed Tel number to +86-20-29019902 Changed CD information in Chapter 1.2 Updated section about 1.5 Selection and Ordering Data |
| 23 Feb., 2017 | 1.2.2 | v.2.0.7 | Added note about PD connection |
| 24 Jul., 2017 | 3.0.0 | v.3.0.0 | Firmware Update |
| 21 Oct., 2017 | 3.0.0 | v.3.0.1 | <ul style="list-style-type: none"> Added "RF output power" information for WiFi interface Added new certificate: EAC Added new product model: R2000-NU Updated router's image Updated network protocol and app Other minor changes |
| 17 Jan., 2018 | 3.0.0 | v.3.0.2 | Updated frequency bands for 3G model |
| 28 Jun., 2018 | 3.0.0 | v.3.0.3 | Revised the company name |
| 12 Dec., 2018 | 3.0.0 | v.3.0.4 | Added the description of the BG96 module |
| 22 Jan., 2019 | 3.0.0 | v.3.0.5 | <ul style="list-style-type: none"> Added the description of the R2000-4M Revised the Certification information Revised the Frequency bands of WIFI |
| 14 Feb., 2019 | 3.0.0 | v.3.0.6 | <ul style="list-style-type: none"> Added the FCC Interference Statement |
| 28 May., 2019 | 3.0.0 | v.3.0.7 | <ul style="list-style-type: none"> Revised the approvals Revised the Regulatory and Type Approval Information |
| 17 Sep., 2019 | 3.0.0 | v.3.0.8 | <ul style="list-style-type: none"> Revised the approvals Revised the Regulatory and Type Approval Information |
| 25 Nov., 2019 | 3.0.0 | v.3.0.9 | <ul style="list-style-type: none"> Revised the description of Update firmware via tftp |
| Mar. 4, 2020 | 3.0.5 | v.3.1.0 | <ul style="list-style-type: none"> Added the related information of IPv6; |

| | | | |
|---------------|-------|---------|--|
| | | | <ul style="list-style-type: none"> • Revised the screenshot of ROS interface; • Revised the parameter description; • Revised the Regulatory and Type Approval Information • Revised the information of IPsec VPN gateway address • Revised the maximum count of filtering • Deleted some redundant descriptions in product specifications • Attach External Antenna (SMA Type) • |
| 27 Apr., 2020 | 3.0.0 | v.3.1.1 | <ul style="list-style-type: none"> • Revised the picture instructions of Attach External Antenna (SMA Type) |
| 25 Dec., 2021 | 3.0.0 | v.3.1.2 | <ul style="list-style-type: none"> • Revised the company name • Revised <i>Regulatory and Type Approval Information</i> • Revised <i>Disclaimer</i> |

Contents

| | | |
|------------------|---|-----------|
| Chapter 1 | Product Overview..... | 11 |
| 1.1 | Key Features..... | 11 |
| 1.2 | Package Contents..... | 11 |
| 1.3 | Specifications..... | 13 |
| 1.4 | Dimensions..... | 14 |
| Chapter 2 | Hardware Installation..... | 15 |
| 2.1 | PIN Assignment..... | 15 |
| 2.2 | LED Indicators..... | 15 |
| 2.3 | Reset Button..... | 16 |
| 2.4 | Ethernet Port..... | 17 |
| 2.5 | Insert or Remove SIM Card..... | 17 |
| 2.6 | Attach External Antenna (SMA Type)..... | 18 |
| 2.7 | Mount the Router..... | 19 |
| 2.8 | Ground the Router..... | 20 |
| 2.9 | Connect the Router to a Computer..... | 20 |
| 2.10 | Power Supply..... | 20 |
| 2.11 | PD Connection (Optional)..... | 21 |
| Chapter 3 | Initial Configuration..... | 22 |
| 3.1 | Configure the PC..... | 22 |
| 3.2 | Factory Default Settings..... | 26 |
| 3.3 | Log in the Router..... | 26 |
| 3.4 | Control Panel..... | 27 |
| 3.5 | Status..... | 28 |
| 3.6 | Interface > Link Manager..... | 31 |
| 3.7 | Interface > LAN..... | 44 |
| 3.8 | Interface > Ethernet..... | 48 |
| 3.9 | Interface > Cellular..... | 49 |
| 3.10 | Interface > WiFi (Optional)..... | 54 |
| 3.11 | Network > Route..... | 62 |
| 3.12 | Network > Firewall..... | 63 |
| 3.13 | Network > IP Passthrough..... | 69 |
| 3.14 | VPN > IPsec..... | 69 |
| 3.15 | VPN > OpenVPN..... | 78 |
| 3.16 | VPN > GRE..... | 91 |
| 3.17 | Services > Syslog..... | 93 |
| 3.18 | Services > Event..... | 94 |
| 3.19 | Services > NTP..... | 97 |
| 3.20 | Services > SMS..... | 98 |
| 3.21 | Services > Email..... | 99 |
| 3.22 | Services > DDNS..... | 100 |
| 3.23 | Services > SSH..... | 101 |
| 3.24 | Services > Web Server..... | 102 |
| 3.25 | Services > Advanced..... | 103 |
| 3.26 | System > Debug..... | 104 |

| | | |
|----------------------|--|------------|
| 3.27 | System > Update..... | 105 |
| 3.28 | System > App Center..... | 106 |
| 3.29 | System > Tools..... | 107 |
| 3.30 | System > Profile..... | 109 |
| 3.31 | System > User Management..... | 111 |
| Chapter 4 | Configuration Examples..... | 113 |
| 4.1 | Cellular..... | 113 |
| 4.1.1 | Cellular Dial-Up..... | 113 |
| 4.1.2 | SMS Remote Control..... | 115 |
| 4.2 | Network..... | 118 |
| 4.2.1 | IPsec VPN..... | 118 |
| 4.2.2 | OpenVPN..... | 122 |
| 4.2.3 | GRE VPN..... | 124 |
| Chapter 5 | Introductions for CLI..... | 127 |
| 5.1 | What Is CLI..... | 127 |
| 5.2 | How to Configure the CLI..... | 128 |
| 5.3 | Commands Reference..... | 129 |
| 5.4 | Quick Start with Configuration Examples..... | 129 |
| Glossary..... | | 136 |

Chapter 1 Product Overview

1.1 Key Features

The Robustel Industrial Dual SIM Cellular VPN Router (R2000) is a rugged cellular router offering state-of-the-art mobile connectivity for machine to machine (M2M) applications.

R2000 is a powerful router developed from RobustOS, a Robustel self-developed and Linux-based operating system which is designed to be used in Robustel devices. The RobustOS includes basic networking features and protocols providing customers with a very good user experience. Meanwhile, Robustel offers a Software Development Kit (SDK) for partners and customers to allow additional customization by using C, C++. It also provides rich Apps to meet fragmented IoT market demands.

1.2 Package Contents

Before installing your R2000 Router, verify the kit contents as following.

Note: The following pictures are for illustration purposes only, not based on their actual sizes.


- 1 x Robustel R2000 Industrial Dual SIM Cellular VPN Router



- 1 x 3-pin 3.5 mm male terminal block for power supply



- 1 x *Quick Start Guide* with download link of other documents or tools



Note: If any of the above items is missing or damaged, please contact your Robustel sales representative.

Optional Accessories (sold separately)

- 3G/4G SMA cellular antenna (stubby/magnet optional)

Stubby antenna



Magnet antenna



- RP-SMA WiFi antenna (stubby/magnet optional)


Stubby antenna



Magnet antenna



- Wall mounting kit



- 35 mm DIN rail mounting kit



- Ethernet cable



- AC/DC power adapter (12V DC, 1.5 A; EU/US/UK/AU plug optional)



1.3 Specifications

Cellular Interface

- Number of antennas: 2 (MAIN + AUX)
- Connector: SMA-K
- SIM: 2 (3.0 V & 1.8 V)
- Standards: GSM/GPRS/EDGE/WCDMA/HSDPA/HSUPA/HSPA+/DC-HSPA+/TD-SCDMA/CDMA (CDMA 1X/EVDO)/FDD LTE/TDD LTE

Ethernet Interface

- Number of ports: 2 x 10/100 ports, 2 x LAN or 1 x LAN + 1 x WAN
- WAN port: Supporting 802.3 at PD feature (optional)
- Magnet isolation protection: 1.5 KV

WiFi Interface (Optional)

- Number of antennas: 2 (WiFi1 + WiFi2)
- Connector: RP-SMA-K
- Standards: 802.11b/g/n, supporting AP and Client modes
- Frequency bands: 2.4 GHz
- Security: WEP, WPA, WPA2
- Encryption: 68/124 AES, TKIP

- Data speed: 2*2 MIMO, 300 Mbps

Others

- 1 x RST button
- LED indicators - 1 x RUN, 1 x PPP, 1 x USR, 3 x RSSI
- Built-in Watchdog, Timer

Power Supply and Consumption


- Connector: 3-pin 3.5 mm female socket
- Input voltage: 9 to 36V DC
- Power consumption: Idle: 100 mA@12 V
Data link: 500 mA (peak) @12 V
- PD feature* (optional): WAN port supported
Input voltage: 48~57V DC

**It is not recommended to use DC power supply and PD power supply simultaneously.*

Physical Characteristics

- Ingress protection: IP30
- Housing & Weight: Metal, 305 g
- Dimensions: 127.5 x 82.5 x 29.5 mm
- Installations: Desktop, wall mounting and 35 mm DIN rail mounting

1.4 Dimensions



Chapter 2 Hardware Installation

2.1 PIN Assignment



| PIN | Polarity |
|-----|----------|
| 1 | Positive |
| 2 | Negative |
| 3 | GND |

2.2 LED Indicators

The R2000 Router has been designed to be placed on a desktop. Below is the bottom view of the R2000.




| Name | Color | Status | Description |
|---------|-------|---|--|
| RUN | Green | On, fast blinking (250 mSec blink time) | Router is powered on (System is initializing) |
| | | On, blinking (500 mSec blink time) | Router starts operating |
| | | Off | Router is powered off |
| PPP | Green | On, solid | Link connection is working |
| | | Off | Link connection is not working |
| USR-SIM | Green | On, blinking | Backup card is being used |
| | | Off | Main card is being used |
| USR-NET | Green | On, solid | Network is joined successfully and worked in an optimum one |
| | | On, blinking | Network is joined successfully but worked in a lower-level than standard |
| | | Off | Network is not joined or joining |

| | | | |
|-------------|-------|--------------------|---|
| USR-OpenVPN | Green | On, solid | OpenVPN connection is established |
| | | Off | OpenVPN connection is not established |
| USR-IPsec | Green | On, solid | IPsec connection is established |
| | | Off | IPsec connection is not established |
| USR-WiFi | Green | On, solid | WiFi is enabled and working properly |
| | | Off | WiFi is disabled or not working properly |
| | Green | On, 3 solid lights | High Signal strength (21-31) is available |
| | | On, 2 solid lights | Medium Signal strength (11-20) is available |
| | | On, 1 solid light | Low Signal strength (1-10) is available |
| | | Off | No signal |
| | | On, blinking | When the network is disconnected, those three signal LEDs are designed as a binary combination code to indicate a series of error report. Blinking: 1 Off: 0 001 AT command failed 010 no SIM card detected 011 need to enter the PIN code 100 need to enter the PUK code 101 registration failed 110 module error 111 not support the module |


Note: You can choose the display type of USR LED. For more details, please refer to **3.25 Service > Advanced**.

2.3 Reset Button



| Function | Operation |
|-------------------------------------|---|
| Reboot | Press and hold the RST button for 2 to 7 seconds under the operating status. |
| Restore to factory default settings | Wait for 3 seconds after powering up the router, press and hold the RST button until all six LEDs start blinking one by one, and release the button to return the router to factory defaults. |


2.4 Ethernet Port



There are two Ethernet ports on R2000 Router, including ETH0 and ETH1. Each has two LED indicators. The yellow one is a link indicator but the green one doesn't mean anything. For details about status, see the table below.

| Indicator | Status | Description |
|----------------|--------------|-------------------------------|
| Link indicator | On, solid | Connection is established |
| | On, blinking | Data is being transferred |
| | Off | Connection is not established |

2.5 Insert or Remove SIM Card



Insert or remove the SIM card as shown in the following steps.

- **Insert SIM card**
 1. Make sure router is powered off.
 2. To remove slot cover, loosen the screws associated with the cover by using a screwdriver and then find the SIM card slot.
 3. To insert SIM card, press the card with finger until you hear a click and then tighten the screws associated with

the cover by using a screwdriver.

4. To put back the cover and tighten the screws associated with the cover by using a screwdriver.

• **Remove SIM card**

1. Make sure router is powered off.
2. To remove slot cover, loosen the screws associated with the cover by using a screwdriver and then find the SIM card slot.
3. To remove SIM card, press the card with finger until it pops out and then take out the card.
4. To put back the cover and tighten the screws associated with the cover by using a screwdriver.


Note:

1. Recommended torque for inserting is 0.5 N.m, and the maximum allowed is 0.7 N.m.
2. Use the specific card when the device is working in extreme temperature (temperature exceeding 40 °C), because the regular card for long-time working in harsh environment will be disconnected frequently.
3. Do not forget to twist the cover tightly to avoid being stolen.
4. Do not touch the metal of the card surface in case information in the card will lose or be destroyed.
5. Do not bend or scratch the card.
6. Keep the card away from electricity and magnetism.
7. Make sure router is powered off before inserting or removing the card.

2.6 Attach External Antenna (SMA Type)

Attach an external SMA antenna to the router’s antenna connector and twist tightly. Make sure the antenna is within the correct frequency range provided by the ISP and with 50 Ohm impedance.

Note: Recommended torque for tightening is 0.35 N.m.




2.7 Mount the Router

The router can be placed on a desktop or mounted to a wall or a 35 mm DIN rail.

Two methods for mounting the router


- Wall mounting (measured in mm)



Use 4 pcs of M2.5*4 flat head Phillips screws to fix the wall mounting kit to the router, and then use 2 pcs of M3 drywall screws to mount the router associated with the wall mounting kit on the wall.

Note: Recommended torque for mounting is 0.5 N.m, and the maximum allowed is 0.7 N.m.


- DIN rail mounting (measured in mm)



Use 3 pcs of M3*6 flat head Phillips screws to fix the DIN rail to the router, and then hang the DIN rail on the mounting bracket. It is necessary to choose a standard bracket.

Note: Recommended torque for mounting is 1.0 N.m, and the maximum allowed is 1.2 N.m.


2.8 Ground the Router



Router grounding helps prevent the noise effect due to electromagnetic interference (EMI). Connect the router to the site ground wire by the ground screw before powering on.

Note: This product is appropriate to be mounted on a sound grounded device surface, such as a metal panel.

2.9 Connect the Router to a Computer




Connect an Ethernet cable to the port marked ETH0 or ETH1 at the bottom of the router, and connect the other end of the cable to your computer.

2.10 Power Supply

CONNECTING THE POWER CABLE

| COLOR | POLARITY |
|--------|----------|
| RED | + |
| YELLOW | - |




R2000 router supports reverse polarity protection, but always refers to the figure above to connect the power adapter correctly. There are two cables associated with the power adapter. Following to the color of the head, connect the cable marked red to the positive pole through a terminal block, and connect the yellow one to the negative in the same way.

Note: The range of power voltage is 9 to 26V DC (A014401, A014402, A014403, A014404, A014405, A014406, A014701, A014702, A014703, A014704, A014705, A014706) or 9 to 36V DC.

2.11 PD Connection (Optional)

If you would like to power the R2000 Router through the Ethernet port, please refer to the following topology to connect the R2000 to a PSE (Power Sourcing Equipment). The range of PoE power voltage is 48~57V DC.

Note: It is not recommended to use DC power supply and PD power supply simultaneously.



Chapter 3 Initial Configuration


The router can be configured through your web browser that including IE 8.0 or above, Chrome and Firefox, etc. A web browser is included as a standard application in the following operating systems: Linux, Mac OS, Windows 98/NT/2000/XP/Me/Vista/7/8, etc. It provides an easy and user-friendly interface for configuration. There are various ways to connect the router, either through an external repeater/hub or connect directly to your PC. However, make sure that your PC has an Ethernet interface properly installed prior to connecting the router. You must configure your PC to obtain an IP address through a DHCP server or a fixed IP address that must be in the same subnet as the router. If you encounter any problems accessing the router web interface, it is advisable to uninstall your firewall program on your PC, as this tends to cause problems accessing the IP address of the router.

3.1 Configure the PC


There are two methods to get IP address for the PC. One is to obtain an IP address automatically from “Local Area Connection”, and another is to configure a static IP address manually within the same subnet of the router. Please refer to the steps below.

Here take **Windows 7** as example, and the configuration for windows system is similar.

1. Click **Start > Control panel**, double-click **Network and Sharing Center**, and then double-click **Local Area Connection**.




2. Click **Properties** in the window of **Local Area Connection**




Status.

3. Choose **Internet Protocol Version 4 (TCP/IPv4)** and click **Properties**.





4. Choose **Internet Protocol Version 6 (TCP/IPv6)** and click **Properties**.




5. Two ways for configuring the IP address of PC.


Obtain an IP address automatically from the DHCP server, click "**Obtain an IP address automatically**";





Manually configure the PC with a static IP address on the same subnet as the router address, click and configure **"Use the following IP address"**;





6. Click **OK** to finish the configuration.

3.2 Factory Default Settings

Before configuring your router, you need to know the following default settings.


| Item | Description |
|-------------|-------------------------------------|
| Username | admin |
| Password | admin |
| ETH0 | 192.168.0.1/255.255.255.0, LAN mode |
| ETH1 | 192.168.0.1/255.255.255.0, LAN mode |
| DHCP Server | Enabled |

3.3 Log in the Router

To log in to the management page and view the configuration status of your router, please follow the steps below.

1. On your PC, open a web browser such as Internet Explorer, Google or Firebox, etc.
2. From your web browser, type the IP address of the router into the address bar and press enter. The default IP address of the router is <http://192.168.0.1/>, though the actual address may vary.

Note: If a SIM card with a public IP address is inserted in the router, enter this corresponding public IP address in the browser's address bar to access the router wirelessly.



3. In the login page, enter the username and password, choose language and then click **LOGIN**. The default username and password are "admin".

Note: If enter the wrong username or password over 6 times, the login web will be locked for 5 minutes.



3.4 Control Panel


After logging in, the home page of the R2000 Router’s web interface is displayed, for example.








From the homepage, users can perform operations such as saving the configuration, restarting the router, and logging out.




Using the original user name and password to log in the router, the page will pop up the following tab

⚠ It is strongly recommended to change the default password. x

It is strongly recommended for security purposes that you change the default username and/or password. Click the  button to close the popup. To change your username and/or password, see **3.31 System > User Management**.

| Control Panel | | |
|---------------|--|---|
| Item | Description | Button |
| Save & Apply | Click to save the current configuration into router's flash and apply the modification on every configuration page, to make the modification taking effect. |  |
| Reboot | Click to reboot the router. If the Reboot button is yellow, it means that some completed configurations will take effect only after reboot. |  |
| Logout | Click to log the current user out safely. After logging out, it will switch to login page. Shut down web page directly without logout, the next one can login web on this browser without a password before timeout. |  |
| Submit | Click to save the modification on current configuration page. |  |
| Cancel | Click to cancel the modification on current configuration page. |  |

Note: The steps of how to modify configuration are as bellow:

1. Modify in one page;
2. Click  under this page;
3. Modify in another page;
4. Click  under this page;
5. Complete all modification;
6. Click .

3.5 Status

This page allows you to view the System Information, Internet Status and LAN Status of your router.

System Information

| ^ System Information | |
|-------------------------|-------------------------|
| Device Model | R2000 |
| System Uptime | 0 days, 06:17:32 |
| System Time | Thu Jul 6 17:28:51 2017 |
| RAM Usage | 17M Free/64M Total |
| Firmware Version | 3.0.0 |
| Hardware Version | 1.0 |
| Kernel Version | 3.10.49 |
| Serial Number | 111111111 |

| System Information | |
|--------------------|--|
| Item | Description |
| Device Model | Show the model name of your device. |
| System Uptime | Show the current amount of time the router has been connected. |
| System Time | Show the current system time. |
| RAM Usage | Show the free memory and the total memory. |
| Firmware Version | Show the firmware version running on the router. |
| Hardware Version | Show the current hardware version. |
| Kernel Version | Show the current kernel version. |
| Serial Number | Show the serial number of your device. |

Internet Status

| ^ Internet Status | |
|-------------------------|-------------------------------------|
| Uptime | 0 days, 00:00:40 |
| Active IPv4 Link | WWAN1 |
| IPv4 Address | 10.161.3.12/255.0.0.0 |
| IPv4 Gateway | 10.0.0.1 |
| IPv4 DNS | 120.80.80.80 221.5.88.88 |
| Active IPv6 Link | WWAN1 |
| IPv6 Address | 2408:84f3:2d:9e2c:1e:10ff:fe1f:0/64 |
| IPv6 Gateway | fe80::4e54:99ff:fe45:e5d5 |
| IPv6 DNS | 2408:805d:8:: 2408:805c:4008:: |

| Internet Status | |
|-----------------------|--|
| Item | Description |
| Uptime | Show the current amount of time the link has been connected. |
| IPv4 Link Description | Show the currently online link: WWAN1, WWAN2, WAN or WLAN. |
| IPv4 Address | Show the IPv4 address of current link. |
| IPv4 Gateway | Show the IPv4 gateway address of the current link. |
| IPv4 DNS | Show the current primary IPv4 DNS server and secondary server. |
| IPv6 Link Description | Show the currently online link: WWAN1, WWAN2, WAN or WLAN. |
| IPv6 Address | Show the IPv6 address of current link. |
| IPv6 Gateway | Show the IPv6 gateway address of the current link. |
| IPv6 DNS | Show the current primary IPv6 DNS server and secondary server. |


LAN Status

| ^ LAN Status | |
|------------------------------|--|
| IP Address | 192.168.0.1/255.255.255.0 |
| Active IPv6 Address | 2121:da8:202:10:36fa:40ff:fe18:68e3/64 |
| Inactive IPv6 Address | |
| MAC Address | 34:FA:40:18:68:E3 |

| LAN Status | |
|-----------------------|--|
| Item | Description |
| IP Address | Show the IP address and the Netmask of the router. |
| IPv6 Address | Show the IPv6 address and prefix length obtained by the router along with the current online link. |
| Inactive IPv6 Address | Show the IPv6 address and prefix length obtained by the router along with the current backup link. |
| MAC Address | Show the MAC address of the router. |

3.6 Interface > Link Manager

This section allows you to setup the link connection.



| General Settings @ Link Manager | | |
|---------------------------------|--|-------------|
| Item | Description | Default |
| Primary Link | Select from “WWAN1”, “WWAN2”, “WAN” or “WLAN”. <ul style="list-style-type: none"> WWAN1: Select to make SIM1 as the primary wireless link WWAN2: Select to make SIM2 as the primary wireless link WAN: Select to make WAN Ethernet port as the primary wired link Note: WAN link is available only if enable eth0 as WAN port in Interface > Ethernet > Ports > Port Settings. WLAN: Select to make WLAN as the primary wireless link Note: WLAN link is available only if enable WiFi as Client mode, please refer to 3.10 Interface > WiFi. | WWAN1 |
| Backup Link | Select from “WWAN1”, “WWAN2”, “WAN”, “WLAN” or “None”. <ul style="list-style-type: none"> WWAN1: Select to make SIM1 as backup wireless link WWAN2: Select to make SIM2 as backup wireless link WAN: Select to make WAN Ethernet port as the primary wired link Note: WAN link is available only if enable eth0 as WAN port in Interface > Ethernet > Ports > Port Settings. WLAN: Select to make WLAN as the primary wireless link Note: WLAN link is available only if enable WiFi as Client mode, please refer to 3.10 Interface > WiFi. None: Do not select any backup link | WWAN2 |
| Backup Mode | Select from “Cold Backup”, “Warm Backup” or “Load Balancing”. <ul style="list-style-type: none"> Cold Backup: The inactive link is offline on standby Warm Backup: The inactive link is online on standby Load Balancing: Use two links simultaneously Note: R2000 do not support warm backup and load balancing in the situation of two WWAN links. | Cold Backup |
| Revert Interval | Specify the number of minutes that elapses before the primary link is checked if a backup link is being used in cold backup mode. 0 means disable checking. Note: Revert interval is available only under the cold backup mode. | 0 |
| Emergency Reboot | Click the toggle button to enable/disable this option. Enable to reboot the whole system if no links available. | OFF |

Note: Click for help.

Link Settings allows you to configure the parameters of link connection, including WWAN1/WWAN2, WAN and WLAN. It is recommended to enable Ping detection to keep the router always online. The Ping detection increases the reliability and also saves the data traffic.

| ^ Link Settings | | | | | |
|-----------------|-------|-------------|----------------------|----------------------|--|
| Index | Type | Description | IPv4 Connection Type | IPv6 Connection Type | |
| 1 | WWAN1 | admin | DHCP | SLAAC | |
| 2 | WWAN2 | | DHCP | SLAAC | |
| 3 | WAN | | DHCP | SLAAC | |
| 4 | WLAN | | DHCP | SLAAC | |

Click on the right-most of WWAN1/WWAN2 to enter the configuration window.

WWAN1/WWAN2

Link Manager

^ General Settings

Index

Type

Description

IPv6 Enable ON OFF

The window is displayed as below when enabling the **“Automatic APN Selection”** option

^ WWAN Settings

Automatic APN Selection ON OFF

Dialup Number

Authentication Type

Switch SIM By Data Allowance ON OFF ?

Data Allowance ?

Billing Day ?

The window is displayed as below when disabling the **“Automatic APN Selection”** option.

^ WWAN Settings

Automatic APN Selection ON OFF

APN

Username

Password

Dialup Number

Authentication Type v

PPP Preferred ON OFF ?

Switch SIM By Data Allowance ON OFF ?

Data Allowance ?

Billing Day ?

^ IPv6 LAN Settings

Connection Type v

IPv6 Prefix

IPv6 NAT Enable ON OFF

^ Ping Detection Settings ?

Enable ON OFF

IPv4 Primary Server

IPv4 Secondary Server

IPv6 Primary Server

IPv6 Secondary Server

Interval ?

Retry Interval ?

Timeout ?

Max Ping Tries ?

^ Advanced Settings

IPv4 NAT Enable ON OFF

Upload Bandwidth ?

Download Bandwidth

Overridden Primary DNS

Overridden Secondary DNS

Overridden IPv6 Primary DNS

Overridden IPv6 Secondary DNS

Debug Enable ON OFF

Verbose Debug Enable ON OFF

| Link Settings (WWAN) | | |
|------------------------------|--|-----------|
| Item | Description | Default |
| General Settings | | |
| Index | Indicate the ordinal of the list. | -- |
| Type | Show the type of the link. | WWAN1 |
| Description | Enter a description for this link. | Null |
| IPv6 | Click the toggle button to enable/disable IPv6. | OFF |
| WWAN Settings | | |
| Automatic APN Selection | Click the toggle button to enable/disable the "Automatic APN Selection" option. After enabling, the device will recognize the access point name automatically. Alternatively, you can disable this option and manually add the access point name. | ON |
| APN | Enter the Access Point Name for cellular dial-up connection, provided by local ISP. | internet |
| Username | Enter the username for cellular dial-up connection, provided by local ISP. | Null |
| Password | Enter the password for cellular dial-up connection, provided by local ISP. | Null |
| Dialup Number | Enter the dialup number for cellular dial-up connection, provided by local ISP. | *99***1# |
| Authentication Type | Select from "Auto", "PAP" or "CHAP" as the local ISP required. | Auto |
| PPP Preferred | The PPP dial-up method is preferred. | OFF |
| Switch SIM By Data Allowance | Click the toggle button to enable/disable this option. After enabling, it will switch to another SIM when the data limit reached. Note: Only used for dual-SIM backup. | OFF |
| Data Allowance | Set the monthly data traffic limitation. The system will record the data traffic statistics when data traffic limitation (MiB) is specified. The traffic record will be displayed in Interface > Link Manager > Status > WWAN Data Usage Statistics . 0 means disable data traffic record. | 0 |
| Billing Day | Specify the monthly billing day. The data traffic statistics will be recalculated from that day. | 1 |
| IPv6 LAN Settings | | |
| Connection Type | Select the link to assign an IPv6 prefix to the local area network. | Delegated |

| Link Settings (WWAN) | | |
|--------------------------------|---|----------------------|
| Item | Description | Default |
| IPv6 prefix | Set the static IPv6 prefix assigned by the link to the LAN. | Null |
| Enable IPv6 NAT | Set the link to enable IPv6 NAT. | OFF |
| Ping Detection Settings | | |
| Enable | Click the toggle button to enable/disable the ping detection mechanism, a keepalive policy of the router. | ON |
| IPv4 Primary Server | Router will ping this primary address/domain name to check that if the current IPv4 connectivity is active. | 8.8.8.8 |
| IPv4 Secondary Server | Router will ping this secondary address/domain name to check that if the current IPv4 connectivity is active. | 114.114.114.114 |
| IPv6 Primary Server | Router will ping this primary address/domain name to check that if the current IPv6 connectivity is active. | 2001:4860:4860::8888 |
| IPv6 Secondary Server | Router will ping this secondary address/domain name to check that if the current IPv6 connectivity is active. | 2400:da00:2::29 |
| Interval | Set the ping interval. | 300 |
| Retry Interval | Set the ping retry interval. When ping failed, the router will ping again every retry interval. | 5 |
| Timeout | Set the ping timeout. | 3 |
| Max Ping Tries | Set the max ping tries. Switch to another link or take emergency action if the max continuous ping tries reached. | 3 |
| Advanced Settings | | |
| NAT Enable | Click the toggle button to enable/disable the Network Address Translation option. | ON |
| Upload Bandwidth | Set the upload bandwidth used for QoS, measured in kbps. | 10000 |
| Download Bandwidth | Set the download bandwidth used for QoS, measured in kbps. | 10000 |
| Specify Primary DNS | Defines the primary IPv4 DNS server used by the link. | Null |
| Specify Secondary DNS | Defines the secondary IPv4 DNS server used by the link. | Null |
| Specify IPv6 Primary DNS | Defines the primary IPv6 DNS server used by the link. | Null |
| Specify IPv6 Secondary DNS | Defines the secondary IPv6 DNS server used by the link. | Null |
| Debug Enable | Click the toggle button to enable/disable this option. Enable for debugging information output. | ON |
| Verbose Debug Enable | Click the toggle button to enable/disable this option. Enable for verbose debugging information output. | OFF |

WAN

Router will obtain IP automatically from DHCP server if choosing “**DHCP**” as **IPv4 connection type**. The window is displayed as below.

The router will automatically obtain an IPv6 prefix from the DHCP server When SLAAC is selected for **IPv6 Connection Type**.

Link Manager

^ **General Settings**

Index

Type

Description

IPv6 Enable ON OFF

IPv4 Connection Type

IPv6 Connection Type

The window is displayed as below when choosing “**Static**” as the **IPv4 connection type** and **IPv6 connection type**.

^ **General Settings**

Index

Type

Description

IPv6 Enable ON OFF

IPv4 Connection Type

IPv6 Connection Type

^ **Static Address Settings**

IP Address ?

Gateway

Primary DNS

Secondary DNS

^ **IPv6 Static Address Settings**

IPv6 Address

IPv6 Gateway

IPv6 Primary DNS

IPv6 Secondary DNS

The window is displayed as below when choosing “**PPPoE**” as the **IPv4 connection type** and **IPv6 connection type**

^ General Settings

Index
 Type
 Description
 IPv6 Enable ON OFF

IPv4 Connection Type
 IPv6 Connection Type

 Address Mode

^ PPPoE Settings

Username
 Password
 Authentication Type
 PPP Expert Options ⓘ

^ Ping Detection Settings ⓘ

Enable ON OFF
 IPV4 Primary Server
 IPV4 Secondary Server
 IPV6 Primary Server
 IPV6 Secondary Server
 Interval ⓘ
 Retry Interval ⓘ
 Timeout ⓘ
 Max Ping Tries ⓘ

^ Advanced Settings

IPv4 NAT Enable ON OFF
 MTU ⓘ
 Upload Bandwidth ⓘ
 Download Bandwidth
 Overridden Primary DNS
 Overridden Secondary DNS
 Overridden IPv6 Primary DNS
 Overridden IPv6 Secondary DNS
 Debug Enable ON OFF
 Verbose Debug Enable ON OFF

| Link Settings (WAN) | | |
|-------------------------------------|---|----------------------|
| Item | Description | Default |
| General Settings | | |
| Index | Indicate the ordinal of the list. | -- |
| Type | Show the type of the link. | WAN |
| Description | Enter a description for this link. | Null |
| Enable IPv6 | Click the toggle button to enable / disable IPv6. | OFF |
| IPv4 Connection Type | Select from "DHCP", "Static" or "PPPoE". | DHCP |
| IPv6 Connection Type | Select from "SLAAC", "DHCPv6", "Static" or "PPPoE". | SLAAC |
| Address Type | Select from "SLAAC" or "DHCPv6". | SLAAC |
| IPv4 Static Address Settings | | |
| IP Address | Set the IP address with Netmask which can access the Internet. IP address with Netmask, e.g. 192.168.1.1/24 | Null |
| Gateway | Set the gateway of the IP address in WAN port. | Null |
| Primary DNS | Set the primary DNS. | Null |
| Secondary DNS | Set the secondary DNS. | Null |
| IPv6 Static Address Settings | | |
| IPv6 Address | Set the IP address with Netmask which can access the Internet. IP address with Netmask, e.g. 2521:da8:202:10::20/64。 | Null |
| Gateway | Set the gateway of the IPv6 address in WAN port. | Null |
| IPv6 Primary DNS | Defines the primary IPv6 DNS server used by the link. | Null |
| IPv6 Secondary DNS | Defines an alternative IPv6 DNS server for the link. | Null |
| PPPoE Settings | | |
| Username | Enter the username provided by your Internet Service Provider. | Null |
| Password | Enter the password provided by your Internet Service Provider. | Null |
| Authentication Type | Select from "Auto", "PAP" or "CHAP" as the local ISP required. | Auto |
| PPP Expert Options | Enter the PPP Expert options used for PPPoE dialup. You can enter some other PPP dial strings in this field. Each string can be separated by a semicolon. | Null |
| IPv6 LAN Ping Settings | | |
| Connection Type | Select the link to assign an IPv6 prefix to the local area network. | Delegated |
| IPv6 Prefix | Set the static IPv6 prefix assigned by the link to the LAN. | Null |
| Enable IPv6 NAT | Set the link to enable IPv6 NAT. | OFF |
| Ping Detection Settings | | |
| Enable | Click the toggle button to enable/disable the ping detection mechanism, a keepalive policy of the router. | ON |
| Primary Server | Router will ping this primary address/domain name to check that if the current connectivity is active. | 8.8.8.8 |
| Secondary Server | Router will ping this secondary address/domain name to check that if the current connectivity is active. | 114.114.114.114 |
| IPv6 Primary Server | The router pings the primary address / domain name to detect whether the current IPv6 connection is always present. | 2001:4860:4860::8888 |

| | | |
|-----------------------------------|---|-----------------|
| IPv6 Secondary Server | The router pings the alternate address / domain name to detect whether the current IPv6 connection is always present. | 2400:da00:2::29 |
| Interval | Set the ping interval. | 300 |
| Retry Interval | Set the ping retry interval. When ping failed, the router will ping again every retry interval. | 5 |
| Timeout | Set the ping timeout. | 3 |
| Max Ping Tries | Set the max ping tries. Switch to another link or take emergency action if the max continuous ping tries reached. | 3 |
| Advanced Settings | | |
| NAT Enable | Click the toggle button to enable/disable the Network Address Translation option. | ON |
| MTU | Enter the Maximum Transmission Unit. | 1500 |
| Upload Bandwidth | Enter the upload bandwidth used for QoS, measured in kbps. | 10000 |
| Download Bandwidth | Enter the download bandwidth used for QoS, measured in kbps. | 10000 |
| Specify Primary DNS | Defines the primary IPv4 DNS server used by the link. | Null |
| Specify Secondary DNS | Defines the secondary IPv4 DNS server for the link. | Null |
| Specify IPV6 Primary DNS server | Defines the primary IPv6 DNS server used by the link. | Null |
| Specify IPv6 secondary DNS server | Defines the secondary IPv6 DNS server for the link. | Null |
| Debug Enable | Click the toggle button to enable/disable this option. Enable for debugging information output. | ON |
| Verbose Debug Enable | Click the toggle button to enable/disable this option. Enable for verbose debugging information output. | OFF |

WLAN

Router will obtain IP automatically from the WLAN AP if choosing “DHCP” as the connection type. The specific parameter configuration of SSID is shown as below.

Link Manager

^ **General Settings**

Index

Type

Description

IPv6 Enable OFF

IPv4 Connection Type

^ **WLAN Settings**

SSID

Connect to Hidden SSID OFF

Password

The window is displayed as below when choosing “Static” as the connection type.

^ General Settings

Index

Type

Description

IPv6 Enable ON OFF

IPv4 Connection Type

^ Static Address Settings

IP Address ?

Gateway

Primary DNS

Secondary DNS

R2000 Router does not support the **PPPoE** WLAN Connection Type.

^ IPv6 LAN Settings

Connection Type

IPv6 Prefix

IPv6 NAT Enable ON OFF

^ Ping Detection Settings ?

Enable ON OFF

IPv4 Primary Server

IPv4 Secondary Server

IPv6 Primary Server

IPv6 Secondary Server

Interval ?

Retry Interval ?

Timeout ?

Max Ping Tries ?

^ Advanced Settings

IPv4 NAT Enable ON OFF

MTU ?

Upload Bandwidth ?

Download Bandwidth

Overridden Primary DNS

Overridden Secondary DNS

Overridden IPv6 Primary DNS

Overridden IPv6 Secondary DNS

Debug Enable ON OFF

Verbose Debug Enable ON OFF


| Link Settings (WLAN) | | |
|--------------------------------|--|-----------|
| Item | Description | Default |
| General Settings | | |
| Index | Indicate the ordinal of the list. | -- |
| Type | Show the type of the link. | WLAN |
| Description | Enter a description for this link. | Null |
| Enable Ipv6 | Click the toggle button to enable/disable IPv6. | OFF |
| Connection Type | Select from "DHCP" or "Static". | DHCP |
| WLAN Settings | | |
| SSID | Enter a 1-32 characters SSID which your router wants to connect. SSID (Service Set Identifier) is the name of your wireless network. | router |
| Connect to Hidden SSID | Click the toggle button to enable/disable this option. When router works as Client mode and needs to connect any access point which has hidden SSID, you need to enable this option. | OFF |
| Password | Enter an 8-63 characters password of the access point which your router wants to connect. | Null |
| Static Address Settings | | |
| IP Address | Enter the IP address with Netmask which can access the Internet, e.g. 192.168.1.1/24 | Null |
| Gateway | Enter the IP address of WiFi AP. | Null |
| Primary DNS | Set the primary DNS. | Null |
| Secondary DNS | Set the secondary DNS. | Null |
| IPv6 LAN Settings | | |
| Connection Type | Select link to assign IPv6 prefix to LAN | Delegated |
| IPv6 Prefix | Set the static IPv6 prefix assigned by the link to the LAN | Null |
| Enable IPv6 NAT | Set the link to enable IPv6 NAT | OFF |
| Ping Detection Settings | | |
| Enable | Click the toggle button to enable/disable the ping detection mechanism, a keepalive policy of the router. | ON |
| Primary Server | Router will ping this primary address/domain name to check that if the | 8.8.8.8 |


| | | |
|-----------------------------------|---|------------------------------|
| | current connectivity is active. | |
| Secondary Server | Router will ping this secondary address/domain name to check that if the current connectivity is active. | 114.114.1 14.114 |
| IPv6 Primary Server | Router will ping this primary address/domain name to check that if the current IPv6 connectivity is active. | 2001:4860 :4860::888 8 |
| IPv6 Secondary Server | Router will ping this secondary address/domain name to check that if the current IPv6 connectivity is active. | 2400:da00 :2::29 |
| Interval | Set the ping interval. | 300 |
| Retry Interval | Set the ping retry interval. When ping failed, the router will ping again every retry interval. | 5 |
| Timeout | Set the ping timeout. | 3 |
| Max Ping Tries | Set the max ping tries. Switch to another link or take emergency action if the max continuous ping tries reached. | 3 |
| Advance Settings | | |
| NAT Enable | Click the toggle button to enable/disable the Network Address Translation option. | ON |
| MTU | Enter the Maximum Transmission Unit. | 1500 |
| Upload Bandwidth | Enter the upload bandwidth used for QoS, measured in kbps. | 10000 |
| Download Bandwidth | Enter the download bandwidth used for QoS, measured in kbps. | 10000 |
| Specify Primary DNS | Defines the primary IPv4 DNS server used by the link. | Null |
| Specify Secondary DNS | Defines the secondary IPv4 DNS server for the link. | Null |
| Specify IPv6 Primary DNS server | Defines the primary IPv6 DNS server used by the link. | Null |
| Specify IPv6 secondary DNS server | Defines the secondary IPv6 DNS server for the link. | Null |
| Debug Enable | Click the toggle button to enable/disable this option. Enable for debugging information output. | ON |
| Verbose Debug Enable | Click the toggle button to enable/disable this option. Enable for verbose debugging information output. | OFF |

Status

This page allows you to view the status of link connection and clear the monthly data usage statistics.

| Link Manager | Status | | | |
|--|-----------|-----------|--------------|------------------|
| ^ Link Status ... | | | | |
| Index | IPv4 Link | IPv6 Link | Status | Uptime |
| 1 | WWAN1 | WWAN1 | Connected | 0 days, 00:01:12 |
| 2 | WWAN2 | WWAN2 | Disconnected | |

Click the right-most button  to select the connection status of the current link.



Click the row of the link, and it will show the details information of the current link connection under the row.

^ Link Status

| Index | IPv4 Link | IPv6 Link | Status | Uptime |
|-------|-----------|-----------|-----------|------------------|
| 1 | WWAN1 | WWAN1 | Connected | 0 days, 06:54... |

Index 1

IPv4 Link WWAN1

IPv6 Link WWAN1

Status Connected

IPv4 Interface wwan

IPv6 Interface wwan

Uptime 0 days, 06:54:37

IPv4 Address 10.37.98.229/255.255.255.252

IPv4 Gateway 10.37.98.230

IPv4 DNS 120.80.80.80 221.5.88.88

IPv6 Address 2408:84f3:1034:96f9:1e:10ff:fe1f:0/64

IPv6 Gateway fe80::4e54:99ff:fe45:e5d5

IPv6 DNS 2408:805d:8:: 2408:805c:4008::

RX Packets 712

TX Packets 979

RX Bytes 47530

TX Bytes 80258

| | | | | |
|---|-------|------|---------------|--|
| 2 | WWAN2 | NONE | Disconnect... | |
|---|-------|------|---------------|--|

^ WWAN Data Usage Statistics

WWAN1 Monthly Stats **Clear**

WWAN2 Monthly Stats **Clear**

Click the **Clear** button to clear SIM1 or SIM2 monthly data traffic usage statistics. Data statistics will be displayed only if enable the Data Allowance function in **Interface > Link Manager > Link Settings > WWAN Settings > Data Allowance**.

3.7 Interface > LAN

This section allows you to set the related parameters for LAN port. There are two LAN ports on R2000 Router, including ETH0 and ETH1. The ETH0 and ETH1 can freely choose from lan0 and lan1, but at least one LAN port must be assigned as lan0. The default settings of ETH0 and ETH1 are lan0 and their default IP are 192.168.0.1/255.255.255.0.

LAN

By default, there is a LAN port (lan0) in the list. To begin adding a new LAN port (lan1), please configure ETH0 or ETH1 as lan1 first in **Ethernet > Ports > Port Settings**. Otherwise, the operation will be prompted as “List is full”.

| Index | Interface | IPv4 Address | Netmask | VLAN ID |
|-------|-----------|--------------|---------------|---------|
| 1 | lan0 | 192.168.0.1 | 255.255.255.0 | 0 |

Note: Lan0 cannot be deleted.

You may click **+** to add a new LAN port, or click **X** to delete the current LAN port. Now, click **[edit]** to edit the configuration of the LAN port.

LAN

General Settings

- Index: 1
- Interface: lan0
- IPv4 Address: 192.168.2.1
- Netmask: 255.255.255.0
- IPv6 Address Allocation Type: SLAAC
- MTU: 1500

| General Settings @ LAN | | |
|------------------------------|---|---------------|
| Item | Description | Default |
| Index | Indicate the ordinal of the list. | -- |
| Interface | Show the editing port. Lan1 is available only if it was selected by one of ETH0~ETH1 in Ethernet > Ports > Port Settings . | -- |
| IP Address | Set the IP address of the LAN port. | 192.168.0.1 |
| Netmask | Set the Netmask of the LAN port. | 255.255.255.0 |
| IPv6 Address Assignment Type | Set the method of assigning IPv6 addresses on the LAN side. | SLAAC |
| MTU | Enter the Maximum Transmission Unit. | 1500 |

The window is displayed as below when choosing “Server” as the mode.

^ DHCP Settings

Enable ON OFF

Mode Server v

IP Pool Start

IP Pool End

Subnet Mask

^ DHCP Advanced Settings

Gateway

Primary DNS

Secondary DNS

WINS Server

Lease Time ?

Static Lease ?

Expert Options ?

Debug Enable ON OFF

The window is displayed as below when choosing “Relay” as the mode.

^ DHCP Settings

Enable ON OFF

Mode Relay v

DHCP Server For Relay

^ DHCP Advanced Settings

Debug Enable ON OFF

| LAN | | |
|----------------------|--|---------------|
| Item | Description | Default |
| DHCP Settings | | |
| Enable | Click the toggle button to enable/disable the DHCP function. | ON |
| Mode | Select from “Server” or “Relay”. <ul style="list-style-type: none"> Server: Lease IP address to DHCP clients which have been connected to LAN port Relay: Router can be a DHCP Relay, which will provide a relay tunnel to solve the problem that DHCP Client and DHCP Server are not in a same subnet | Server |
| IP Pool Start | Define the beginning of the pool of IP addresses which will be leased to DHCP clients. | 192.168.0.2 |
| IP Pool End | Define the end of the pool of IP addresses which will be leased to DHCP clients. | 192.168.0.100 |

| LAN | | |
|------------------------|--|---------------|
| Item | Description | Default |
| Subnet Mask | Define the subnet mask of IP address obtained by DHCP clients from DHCP server. | 255.255.255.0 |
| DHCP Server for Relay | Enter the IP address of DHCP relay server. | Null |
| DHCP Advanced Settings | | |
| Gateway | Define the gateway assigned by the DHCP server to the clients, which must be on the same network segment with DHCP address pool. | Null |
| Primary DNS | Define the primary DNS server assigned by the DHCP server to the clients. | Null |
| Secondary DNS | Define the secondary DNS server assigned by the DHCP server to the clients. | Null |
| WINS Server | Define the Windows Internet Naming Service obtained by DHCP clients from DHCP sever. | Null |
| Lease Time | Set the lease time which the client can use the IP address obtained from DHCP server, measured in seconds. | 120 |
| Static lease | Bind a lease to correspond an IP address via a MAC address. format: mac,ip;mac,ip;..., e.g. FF:ED:CB:A0:98:01,192.168.0.200 | Null |
| Expert Options | Enter some other options of DHCP server in this field. format: config-desc;config-desc, e.g. log-dhcp;quiet-dhcp | Null |
| Debug Enable | Click the toggle button to enable/disable this option. Enable for DHCP information output. | OFF |

Multiple IP

| LAN | Multiple IP | Status |
|--|-------------|--------|
| ^ Multiple IP Settings Index Interface IP Address Netmask + | | |

You may click **+** to add a multiple IP to the LAN port, or click **X** to delete the multiple IP of the LAN port. Now, click **✎** to edit the multiple IP of the LAN port.

| Multiple IP | |
|---------------|-------------------------------------|
| ^ IP Settings | |
| Index | <input type="text" value="1"/> |
| Interface | <input type="text" value="lan0"/> v |
| IP Address | <input type="text"/> |
| Netmask | <input type="text"/> |

| IP Settings | | |
|-------------|--|---------|
| Item | Description | Default |
| Index | Indicate the ordinal of the list. | -- |
| Interface | Show the editing port. | -- |
| IP Address | Set the multiple IP address of the LAN port. | Null |
| Netmask | Set the multiple Netmask of the LAN port. | Null |

VLAN Trunk

| LAN | Multiple IP | VLAN Trunk | Status |
|-----------------|-------------|------------|--------|
| ^ VLAN Settings | | | |
| Index | Enable | Interface | VID |
| IP Address | Netmask | + | |

Click **+** to add a VLAN. The maximum count is 8.

| VLAN Trunk | |
|-----------------|---|
| ^ VLAN Settings | |
| Index | <input type="text" value="1"/> |
| Enable | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Interface | <input type="text" value="lan0"/> v |
| VID | <input type="text" value="100"/> |
| IP Address | <input type="text"/> |
| Netmask | <input type="text"/> |

| VLAN Settings | | |
|---------------|---|---------|
| Item | Description | Default |
| Index | Indicate the ordinal of the list. | -- |
| Enable | Click the toggle button to enable/disable this VLAN. Enable to make router can encapsulate and de-encapsulate the VLAN tag. | ON |
| Interface | Choose the interface which wants to enable VLAN trunk function. Select from "lan0" or "lan1" depends on your ETH0 and ETH1's corresponding LAN ports. | lan0 |
| VID | Set the tag ID of VLAN and digits from 1 to 4094. | 100 |
| IP Address | Set the IP address of VLAN port. | Null |
| Netmask | Set the Netmask of VLAN port. | Null |

Status

This section allows you to view the status of LAN connection.

| LAN | Multiple IP | Status | | |
|----------------------------|-------------------|----------------------|---------------------------|------------------|
| ^ Interface Status | | | | |
| Index | Interface | IP Address | Active IPv6 Address | |
| 1 | lan0 | 192.168.0.1/255.2... | 2221:da8:202:10:36fa:4... | |
| ^ Connected Devices | | | | |
| Index | IPv4/IPv6 Address | MAC Address | Interface | Inactive Time |
| 1 | 192.168.0.59 | D0:50:99:A9:2B:80 | lan0 | 0s |
| ^ DHCP Lease Table | | | | |
| Index | IPv4/IPv6 Address | MAC Address or IAID | Interface | Expired Time |
| 1 | 192.168.0.59 | d0:50:99:a9:2b:80 | lan0 | 0 days, 01:51:38 |
| ^ DHCP Lease Table | | | | |
| Index | IP Address | MAC Address | Interface | Expired Time |

Click the row of status, the details status information will be displayed under the row. Please refer to the screenshot below.

| ^ Connected Devices | | | | | | | | | | | | | | |
|--|-------------------|-------------------|-----------|---------------|-------|---|-------------------|--------------|-------------|-------------------|-----------|------|---------------|----|
| Index | IPv4/IPv6 Address | MAC Address | Interface | Inactive Time | | | | | | | | | | |
| 1 | 192.168.0.59 | D0:50:99:A9:2B:80 | lan0 | 0s | | | | | | | | | | |
| <table border="0"> <tr> <td style="padding-right: 10px;">Index</td> <td>1</td> </tr> <tr> <td style="padding-right: 10px;">IPv4/IPv6 Address</td> <td>192.168.0.59</td> </tr> <tr> <td style="padding-right: 10px;">MAC Address</td> <td>D0:50:99:A9:2B:80</td> </tr> <tr> <td style="padding-right: 10px;">Interface</td> <td>lan0</td> </tr> <tr> <td style="padding-right: 10px;">Inactive Time</td> <td>0s</td> </tr> </table> | | | | | Index | 1 | IPv4/IPv6 Address | 192.168.0.59 | MAC Address | D0:50:99:A9:2B:80 | Interface | lan0 | Inactive Time | 0s |
| Index | 1 | | | | | | | | | | | | | |
| IPv4/IPv6 Address | 192.168.0.59 | | | | | | | | | | | | | |
| MAC Address | D0:50:99:A9:2B:80 | | | | | | | | | | | | | |
| Interface | lan0 | | | | | | | | | | | | | |
| Inactive Time | 0s | | | | | | | | | | | | | |

3.8 Interface > Ethernet

This section allows you to set the related parameters for Ethernet. There are two Ethernet ports on R2000 Router, including ETH0 and ETH1. The ETH0 on the router can be configured as either a WAN port or LAN port, also can be assigned as a PoE port, while ETH1 can only be configured as a LAN port. The default settings of ETH0 and ETH1 are lan0 and their default IP are 192.168.0.1/255.255.255.0.

| Ports | Status | |
|------------------------|--------|-----------------|
| ^ Port Settings | | |
| Index | Port | Port Assignment |
| 1 | eth0 | lan0 |
| 2 | eth1 | lan0 |

Click button of eth0 to configure its parameters, and modify the port assignment parameters of eth0 in the pop-up window.

Ports

^ Port Settings

Index

Port

Port Assignment

| Port Settings | | |
|-----------------|--|---------|
| Item | Description | Default |
| Index | Indicate the ordinal of the list. | -- |
| Port | Show the editing port, read only. | -- |
| Port Assignment | Choose the Ethernet port's type, as a WAN port or LAN port. When setting the port as a LAN port, you can click the drop-down list to select from "lan0" or "lan1". | lan0 |

This column allows you to view the status of Ethernet port.

Ports | **Status**

^ Port Status

| Index | Port | Link |
|-------|------|------|
| 1 | eth0 | Down |
| 2 | eth1 | Up |

Click the row of status, the details status information will be displayed under the row. Please refer to the screenshot below.

^ Port Status

| Index | Port | Link |
|-------|------|------|
| 1 | eth0 | Down |
| 2 | eth1 | Up |

Index 2
Port eth1
Link Up

3.9 Interface > Cellular

This section allows you to set the related parameters of Cellular. The R2000 Router has two SIM card slots, but do not support two SIM cards online simultaneously due to its single-module design. If insert single SIM card at the first time, SIM1 slot and SIM2 slots are available.

Cellular | **Status** | **AT Debug**

^ Advanced Cellular Settings

| Index | SIM Card | Phone Number | Network Type | Band Select Type | |
|-------|----------|--------------|--------------|------------------|--|
| 1 | SIM1 | | Auto | All | |
| 2 | SIM2 | | Auto | All | |

Click on the right-most of SIM 1 to edit the parameters.

Cellular

^ General Settings

| | |
|--------------|-------------------------------------|
| Index | <input type="text" value="1"/> |
| SIM Card | <input type="text" value="SIM1"/> v |
| Phone Number | <input type="text"/> |
| PIN Code | <input type="text"/> ? |
| Extra AT Cmd | <input type="text"/> ? |
| Telnet Port | <input type="text" value="0"/> ? |

The window is displayed as below when choosing "Auto" as the network type.

^ Cellular Network Settings

| | |
|------------------|---------------------------------------|
| Network Type | <input type="text" value="Auto"/> v ? |
| Band Select Type | <input type="text" value="All"/> v ? |

^ Advanced Settings

| | |
|----------------------|--|
| Debug Enable | <input type="checkbox"/> ON <input type="checkbox"/> OFF |
| Verbose Debug Enable | <input type="checkbox"/> ON <input type="checkbox"/> OFF |

Note: When it is a BG96 module, the options in "Network Type" are as follows:

The window is displayed as below when choosing "Specify" as the band select type.

^ Cellular Network Settings

Network Type ?

Band Select Type ?

^ Band Settings

| | |
|-------------------|------------------------------|
| GSM 900 | <input type="checkbox"/> OFF |
| GSM 1800 | <input type="checkbox"/> OFF |
| WCDMA 850 | <input type="checkbox"/> OFF |
| WCDMA 900 | <input type="checkbox"/> OFF |
| WCDMA 2100 | <input type="checkbox"/> OFF |
| LTE Band 1 | <input type="checkbox"/> OFF |
| LTE Band 3 | <input type="checkbox"/> OFF |
| LTE Band 5 | <input type="checkbox"/> OFF |
| LTE Band 7 | <input type="checkbox"/> OFF |
| LTE Band 8 | <input type="checkbox"/> OFF |
| LTE Band 20 | <input type="checkbox"/> OFF |
| LTE Band 38 (TDD) | <input type="checkbox"/> OFF |
| LTE Band 40 (TDD) | <input type="checkbox"/> OFF |
| LTE Band 41 (TDD) | <input type="checkbox"/> OFF |

^ Advanced Settings

Debug Enable ON OFF

Verbose Debug Enable ON OFF

Note: When the device selection module is BG96, the options in "Network Type" are as follows.

^ Cellular Network Settings

Network Type ?

Band Select Type ?

^ Advanced Settings

Network Type dropdown menu:

- Auto
- 2G Only
- M1 Only
- NB Only

| Cellular | | |
|------------------|--|---------|
| Item | Description | Default |
| General Settings | | |
| Index | Indicate the ordinal of the list. | -- |
| SIM Card | Show the currently editing SIM card. | SIM1 |
| Phone Number | Enter the phone number of the SIM card. | Null |
| PIN Code | Enter a 4-8 characters PIN code used for unlocking the SIM. | Null |
| Extra AT Cmd | Enter the AT commands used for cellular initialization. | Null |
| Telnet Port | Specify the Port listening of telnet service, used for AT over Telnet. | 0 |

| Cellular | | |
|----------------------------------|---|---------|
| Item | Description | Default |
| Cellular Network Settings | | |
| Network Type | <p>Select the cellular network type, which is the network access order. Select from “Auto”, “2G Only”, “2G First”, “3G Only”, “3G First”, “4G Only”, “4G First”.</p> <ul style="list-style-type: none"> Auto: Connect to the best signal network automatically 2G Only: Only the 2G network is connected 2G First: Connect to the 2G Network preferentially 3G Only: Only the 3G network is connected 3G First: Connect to the 3G Network preferentially 4G Only: Only the 4G network is connected 4G First: Connect to the 4G Network preferentially <p>Note: When the device selection module is BG96, select from “Auto”, “2G Only”, “M1 Only”, “NB Only”.</p> <ul style="list-style-type: none"> Auto: Connect to the best signal network automatically 2G Only: Only the 2G network is connected M1 Only: Only the CAT M1 network is connected NB Only: Only the NB-IOT network is connected | Auto |
| Band Select Type | Select from “All” or “Specify”. You may choose certain bands if choosing “Specify”. | All |
| Advanced Settings | | |
| Debug Enable | Click the toggle button to enable/disable this option. Enable for debugging information output. | ON |
| Verbose Debug Enable | Click the toggle button to enable/disable this option. Enable for verbose debugging information output. | OFF |

This section allows you to view the status of the cellular connection.

| Cellular | Status | AT Debug | | |
|----------|--------------|-------------|-----------------|----------------------------|
| ^ Status | | | | |
| Index | Modem Status | Modem Model | IMSI | Registration |
| 1 | Ready | EC25-E | 460015687108599 | Registered to home network |

Click the row of status, the details status information will be displayed under the row.

| ^ Status | | | | |
|--|--------------|-------------|-----------------|----------------------------|
| Index | Modem Status | Modem Model | IMSI | Registration |
| 1 | Ready | EC25-E | 460015687108599 | Registered to home network |
| Index 1 | | | | |
| Modem Status Ready | | | | |
| Modem Model EC25-E | | | | |
| Current SIM SIM1 | | | | |
| Phone Number | | | | |
| IMSI 460015687108599 | | | | |
| ICCID 89860119801073537094 | | | | |
| Registration Registered to home network | | | | |
| Network Provider CHN-UNICOM | | | | |
| Network Type LTE | | | | |
| Signal Strength 27 (-59dBm) | | | | |
| Bit Error Rate 99 | | | | |
| PLMN ID 46001 | | | | |
| Local Area Code 2507 | | | | |
| Cell ID 6074716 | | | | |
| IMEI 866758047488842 | | | | |
| Firmware Version EC25EFAR06A03M4G | | | | |

| Status | |
|------------------|---|
| Item | Description |
| Index | Indicate the ordinal of the list. |
| Modem Status | Show the status of the radio module. |
| Modem Model | Show the model of the radio module. |
| Current SIM | Show the SIM card that your router is using. |
| Phone Number | Show the phone number of the current SIM. Note: This option will be displayed if enter manually in Cellular > Advanced Cellular Settings > SIM1/SIM2 > General Settings > Phone Number . |
| IMSI | Show the IMSI number of the current SIM. |
| ICCID | Show the ICCID number of the current SIM. |
| Registration | Show the current network status. |
| Network Provider | Show the name of Network Provider. |
| Network Type | Show the current network service type, e.g. GPRS. |
| Signal Strength | Show the signal strength detected by the mobile. |
| Bit Error Rate | Show the current bit error rate. |
| PLMN ID | Show the current PLMN ID. |
| Local Area Code | Show the current local area code used for identifying different area. |
| Cell ID | Show the current cell ID used for locating the router. |

| Status | |
|------------------|---|
| Item | Description |
| IMEI | Show the IMEI (International Mobile Equipment Identity) number of the radio module. |
| Firmware Version | Show the current firmware version of the radio module. |

This page allows you to check the AT Debug.

| AT Debug | | |
|-------------|---|---------|
| Item | Description | Default |
| Command | Enter the AT command that you want to send to cellular module in this text box. | Null |
| Result | Show the AT command responded by cellular module in this text box. | Null |
| Send | Click the button to send AT command. | -- |

3.10 Interface > WiFi (Optional)

This section allows you to configure the parameters of two WiFi modes. Router supports both WiFi AP or Client modes, and default as AP.

WiFi AP

Configure Router as WiFi AP

Click **Interface > WiFi > WiFi**, select "AP" as the mode and click "Submit".

Note: Please remember to click **Save & Apply > Reboot** after finish the configuration, so that the configuration can be took effect.

Click the **Access Point** column to configure the parameters of WiFi AP. By default, the security mode is set as "Disabled".

| WiFi | Access Point | Advanced | ACL | Status |
|---------------------------|---|----------|-----|--------|
| ^ General Settings | | | | |
| Enable | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF | | | |
| Wireless Mode | 11bgn Mixed v | | | |
| Channel | Auto v ? | | | |
| SSID | router | | | |
| Broadcast SSID | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF | | | |
| Security Mode | Disabled v ? | | | |

The window is displayed as below when setting “WPA-Personal” as the security mode.

| | | | | |
|---------------------------|---|--|--|--|
| ^ General Settings | | | | |
| Enable | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF | | | |
| Wireless Mode | 11bgn Mixed v | | | |
| Channel | Auto v ? | | | |
| SSID | router | | | |
| Broadcast SSID | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF | | | |
| Security Mode | WPA-Personal v ? | | | |
| WPA Version | Auto v | | | |
| Encryption | Auto v ? | | | |
| PSK Password | v ? | | | |
| Group Key Update Interval | 3600 | | | |

The window is displayed as below when setting “WPA-Enterprise” as the security mode.

| | | | | |
|--------------------------------------|---|--|--|--|
| ^ General Settings | | | | |
| Enable | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF | | | |
| Wireless Mode | 11bgn Mixed v | | | |
| Channel | Auto v ? | | | |
| SSID | router | | | |
| Broadcast SSID | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF | | | |
| Security Mode | WPA-Enterprise v ? | | | |
| WPA Version | Auto v | | | |
| Encryption | Auto v ? | | | |
| Radius Authentication Server Address | v | | | |
| Radius Authentication Server Port | 1812 | | | |
| Radius Server Share Secret | v | | | |
| Group Key Update Interval | 3600 | | | |

The window is displayed as below when setting “WEP” as the security mode.

^ General Settings

Enable ON OFF

Wireless Mode v

Channel v ?

SSID

Broadcast SSID ON OFF

Security Mode v ?

WEP Key ?

| General Settings @ Access Point | | |
|---------------------------------|--|-------------|
| Item | Description | Default |
| Enable | Click the toggle button to enable/disable the WiFi access point option. | OFF |
| Wireless Mode | Select from “11bgn Mixed”, “11b Only”, “11g Only” or “11n Only”. <ul style="list-style-type: none"> 11bgn Mixed: Mix three agreements, for backward compatibility 11b only: IEEE 802.11b, 11Mbit/s~2.4GHz 11g only: IEEE 802.11g, 54Mbit/s~2.4GHz 11n only: IEEE 802.11n, 300Mbps~600Mbps | 11bgn Mixed |
| Channel | Select the frequency channel, including “Auto”, “1”, “2” “13”. <ul style="list-style-type: none"> Auto: Router will scan all frequency channels until the best one is found 1~13 Router will be fixed to work with this channel Following are the frequency of 1~13 channel: <ul style="list-style-type: none"> 1: 2412 MHz 2: 2417 MHz 3: 2422 MHz 4: 2427 MHz 5: 2432 MHz 6: 2437 MHz 7: 2442 MHz 8: 2447 MHz 9: 2452 MHz 10: 2457 MHz 11: 2462 MHz 12: 2467 MHz 13: 2472 MHz | Auto |
| SSID | Enter the Service Set Identifier, the name of your wireless network. The SSID of a client and the SSID of the AP must be identical for the client and AP to be able to communicate with each other. Enter 1 to 32 characters. | router |

| General Settings @ Access Point | | |
|--------------------------------------|---|----------|
| Item | Description | Default |
| Broadcast SSID | Click the toggle button to enable/disable the SSID being broadcast. When enabled, the client can scan your SSID. When disabled, the client cannot scan your SSID. If you want to connect to the router AP, you need to manually enter the SSID of router AP at WiFi client side. | ON |
| Security Mode | Select from "Disabled", "WPA-Personal", "WPA-Enterprise" or "WEP". <ul style="list-style-type: none"> Disabled: User can access the WiFi without password Note: It is strongly recommended for security purposes that you do not choose this kind of mode. WPA-Personal: WiFi Protected Access only provides one password used for Identity Authentication WPA-Enterprise: Provides an authentication interface for EAP which can be authenticated via Radius Authentication Server or other Extended Authentication WEP: Wired Equivalent Privacy provides encryption for wireless device's data transmission | Disabled |
| WPA Version | Select from "Auto", "WPA" or "WPA2". <ul style="list-style-type: none"> Auto: Router will choose automatically the most suitable WPA version WPA2 is a stronger security feature than WPA | Auto |
| Encryption | Select from "Auto", "TKIP" or "AES". <ul style="list-style-type: none"> Auto: Router will choose automatically the most suitable encryption TKIP: Temporal Key Integrity Protocol (TKIP) encryption uses a wireless connection. TKIP encryption can be used for WPA-PSK and WPA 802.1x authentication Note: It's not recommended to use TKIP encryption in 802.11n mode. AES: AES encryption uses a wireless connection. AES can be used for CCMP WPA-PSK and WPA 802.1x authentication. AES is a stronger encryption algorithm than TKIP | Auto |
| PSK Password | Enter the Pre share key password. When router works as AP mode, enter Master key to generate keys for encryption. A PSK Password is used as a basis for encryption methods (or cipher types) in a WLAN connection. The PSK Password should be complicated and as long as possible. For security reasons, this PSK Password should only be disclosed to users who need it, and it should be changed regularly. Enter 8 to 63 characters. | Null |
| Radius Authentication Server Address | Enter the address of radius authentication server. | Null |
| Radius Authentication Server Port | Enter the port of radius authentication server. | 1812 |

| General Settings @ Access Point | | |
|---------------------------------|--|---------|
| Item | Description | Default |
| Radius Server Share Secret | Enter the shared secret of radius authentication server. | Null |
| Group Key Update Interval | Enter the time period of group key renewal. | 3600 |
| WEP Key | Enter the WEP key. The key length should be 10 or 26 hexadecimal digits depending on which WEP key is used, 64 digits or 128 digits. | Null |

WiFi
Access Point
Advanced
ACL
Status

^ Advanced Settings

Max Associated Stations

Beacon Interval ?

DTIM Period ?

RTS Threshold ?

Fragmentation Threshold ?

Transmit Rate v

11N Transmit Rate v

Transmit Power v

Channel Width v ?

Enable WMM ON OFF

Enable Short GI ON OFF ?

Enable AP Isolation ON OFF ?

Debug Level v

| Advanced Settings | | |
|-------------------------|---|---------|
| Item | Description | Default |
| Max Associated Stations | Set the max number of clients allowed to access the router’s AP. | 64 |
| Beacon Interval | Set the interval of time in which the router AP broadcasts a beacon which is used for wireless network authentication. | 100 |
| DTIM Period | Set the delivery traffic indication message period and the router AP will multicast the data according to this period. | 2 |
| RTS Threshold | Set the “request to send” threshold. When the threshold set as 2347, the router AP will not send detection signal before sending data. And when the threshold set as 0, the router AP will send detection signal before sending data. | 2347 |
| Fragmentation Threshold | Set the fragmentation threshold of a WiFi AP. It is recommended that you use the default value 2346. | 2346 |
| Transmit Rate | Set the transmit rate. You can choose Auto or specify a Transmit Rate, including 1Mbps, 2Mbps, 5.5Mbps, 6Mbps, 11Mbps, 12Mbps, 18Mbps, 24Mbps, 36Mbps, 48Mbps, 54Mbps, MCS0, MCS1, MCS2, MCS3, MCS4, MCS5, MCS6 and MCS7. | Auto |
| 11N Transmit Rate | Specify the transmit rate under the IEEE 802.11n mode or let is | Auto |

| Advanced Settings | | |
|---------------------|--|---------|
| Item | Description | Default |
| | default to "Auto". | |
| Transmit Power | Select from "Max", "High", "Medium" or "Low". | Max |
| Channel Width | Select from "Auto", "20MHz" or "40MHz". Note: 40 MHz channel width provides higher available data rate, twice as many as 20 MHz channel width. | Auto |
| Enable WMM | Click the toggle button to enable/disable the WMM option. | ON |
| Enable Short GI | Click the toggle button to enable/disable the Short Guard Interval option. Short GI is a blank time between two symbols, providing a long buffer time for signal delay. Using the Short GI would increase 11% in data rates, but also result in higher packet error rates. | ON |
| Enable AP Isolation | Click the toggle button to enable/disable the AP isolation option. When enabled, the router will isolate all connected wireless devices. The wireless device cannot access the router directly via WLAN. | OFF |
| Debug Level | Select from "verbose", "debug", "info", "notice", "warning" or "none". | none |

WiFi | Access Point | **Advanced** | ACL | Status

^ General Settings

Enable ACL OFF

ACL Mode v ?

^ Access Control List

| Index | Description | MAC Address |
|-------|-------------|-------------|
| + | | |

Click **+** to add a MAC address to the Access Control List. The maximum count for MAC address is 64.

ACL

^ Access Control List

Index

Description

MAC Address

| ACL | | |
|-------------------------|---|---------|
| Item | Description | Default |
| General Settings | | |
| Enable ACL | Click the toggle button to enable/disable this option. | OFF |
| ACL Mode | Select from "Accept" or "Deny". <ul style="list-style-type: none"> Accept: Only the packets fitting the entities of the "Access Control List" can be allowed Deny: All the packets fitting the entities of the "Access Control List" will be denied Note: Router can only allow or deny devices which are included in "Access Control List" at one time. | Accept |

| ACL | | |
|----------------------------|---|---------|
| Item | Description | Default |
| Access Control List | | |
| Index | Indicate the ordinal of the list. | -- |
| Description | Enter a description for this access control list. | Null |
| MAC Address | Add a MAC address here. | Null |

This section allows you to view the status of AP.

WiFi Client

Configure Router as WiFi Client

Click **Interface > WiFi > WiFi**, select “Client” as the mode and click “Submit”.

And then a “WLAN” column will appear under the Interface list.

Click **Interface > Link Manager > Link Settings**, and click the edit button of WLAN, then configure its related parameters.

^ WLAN Settings

SSID

Connect to Hidden SSID ON OFF

Password

Click **Interface > WLAN** to configure the parameters of WiFi Client after setting the mode as Client. Please remember to click **Save & Apply > Reboot** after finish the configuration, so that the configuration can be took effect.

Status

^ WLAN Status

| | |
|--------------|-----------------------------------|
| IPv4 Status | Connected |
| IPv6 Status | Connected |
| Uptime | 0 days, 00:00:12 |
| IPv4 Address | 192.168.10.106/255.255.255.0 |
| IPv4 Gateway | 192.168.10.1 |
| IPv4 DNS | 192.168.10.1 |
| IPv6 Address | 2001:1221::36fa:40ff:fe03:b311/64 |
| IPv6 Gateway | fe80::36fa:40ff:fe18:68be |
| IPv6 DNS | fe80::c06:1dff:fea1:f0ab |
| MAC Address | 34:fa:40:03:b3:11 |

^ Link Status

| | |
|------------|---------------------------|
| Signal | -70 dBm |
| Noise | -95 dBm |
| Width | 20 MHz |
| TX Bitrate | 6.5 MBit/s MCS 0 |
| TX | 3166 bytes (27 packets) |
| RX | 21277 bytes (189 packets) |

^ WPA Status

| | |
|-----------------|-------------------|
| WPA State | COMPLETED |
| Frequency | 2422 |
| BSSID | 88:da:1a:2a:69:bc |
| SSID | routerIpv63000 |
| Mode | station |
| Key Management | WPA2-PSK |
| Pairwise Cipher | CCMP |
| Group Cipher | TKIP |

This window allows you to scan for all available SSIDs in your area. Please click and then click "Scan" to refresh the surrounding SSID.

| ^ Scan Results ... | | | | | |
|---|-----------------|-------------------|-----------|--------|------|
| Index | SSID | MAC Address | Frequency | Signal | Scan |
| 1 | Michael's | 3C:46:D8:23:5D:5A | 2437 | 58 dBm | |
| 2 | Robustel-Client | 34:FA:40:06:7F:8B | 2412 | 58 dBm | |
| 3 | cfg_ap_ssid | 00:23:A7:A3:F2:B8 | 2462 | 59 dBm | |
| 4 | Cao's | 34:FA:40:09:E4:49 | 2437 | 67 dBm | |
| 5 | Anjiu | 88:25:93:D4:CE:A2 | 2437 | 71 dBm | |
| 6 | FT-VIP | 3C:8C:40:D4:47:90 | 2452 | 73 dBm | |
| 7 | FT | 3C:8C:40:D4:47:91 | 2452 | 73 dBm | |

3.11 Network > Route

This section allows you to set the static route. Static route is a form of routing that occurs when a router uses a manually-configured routing entry, rather than information from a dynamic routing traffic. Route Information Protocol (RIP) is widely used in small network with stable use rate. Open Shortest Path First (OSPF) is made router within a single autonomous system and used in large network.

Static Route

| Static Route Status | | | | | |
|--|-------------|-------------|-----------------------|---------|--|
| ^ Static Route Table | | | | | |
| Index | Description | Destination | Netmask/Prefix Length | Gateway | Interface + |

Click to add static routes. The maximum count is 20.

Static Route

^ Static Route

Index:

Description:

Destination:

Netmask/Prefix Length: ?

Gateway:

Interface: v

| Static Route | | |
|--------------|--|---------|
| Item | Description | Default |
| Index | Indicate the ordinal of the list. | -- |
| Description | Enter a description for this static route. | Null |

| Static Route | | |
|-------------------------------------|---|---------|
| Item | Description | Default |
| Destination | Enter the IP address of destination host or destination network. | Null |
| Netmask/ Ipv6 Address Prefix Length | Enter the Netmask of destination host or destination network. | Null |
| Gateway | Define the gateway of the destination. | Null |
| Interface | Choose the corresponding port of the link that you want to configure. | wwan |

Status

This window allows you to view the status of route.

| Static Route | | Status | | | |
|---------------|---------------------|-----------------------|-----------------------|-----------|--------|
| ^ Route Table | | | | | |
| Index | Destination | Netmask/Prefix Length | Gateway | Interface | Metric |
| 1 | 0.0.0.0 | 0.0.0.0 | 192.168.10.1 | wlan0 | 0 |
| 2 | 192.168.0.0 | 255.255.255.0 | 0.0.0.0 | lan0 | 0 |
| 3 | 192.168.10.0 | 255.255.255.0 | 0.0.0.0 | wlan0 | 0 |
| 4 | 2001:1221:: | 64 | :: | wlan0 | 256 |
| 5 | 2001:4860:4860::... | 128 | fe80::36fa:40ff:fe... | wlan0 | 0 |
| 6 | 2400:da00:2::29 | 128 | fe80::36fa:40ff:fe... | wlan0 | 0 |
| 7 | 2421:da8:202:10:: | 64 | :: | lan0 | 256 |
| 8 | fe80:: | 64 | :: | lan0 | 256 |
| 9 | fe80:: | 64 | :: | eth1 | 256 |
| 10 | fe80:: | 64 | :: | wwan | 256 |
| 11 | fe80:: | 64 | :: | wlan0 | 256 |
| 12 | :: | 0 | fe80::36fa:40ff:fe... | wlan0 | 1024 |
| 13 | ff02::1 | 128 | :: | lan0 | 0 |
| 14 | ff02::1 | 128 | :: | wlan0 | 0 |
| 15 | ff02::2 | 128 | :: | wlan0 | 0 |
| 16 | ff02::16 | 128 | :: | lan0 | 0 |
| 17 | ff02::1:2 | 128 | :: | wlan0 | 0 |
| 18 | ff02::1:3 | 128 | :: | lan0 | 0 |
| 19 | ff02::1:ff14:4f32 | 128 | :: | lan0 | 0 |
| 20 | ff00:: | 8 | :: | lan0 | 256 |
| 21 | ff00:: | 8 | :: | eth1 | 256 |
| 22 | ff00:: | 8 | :: | wwan | 256 |
| 23 | ff00:: | 8 | :: | wlan0 | 256 |

3.12 Network > Firewall

This section allows you to set the firewall and its related parameters, including Filtering, Port Mapping and DMZ.

Filtering

The filtering rules can be used to either accept or block certain users or ports from accessing your router. Click

Network> Firewall> Filter. The following information is displayed:

Filtering
Port Mapping
Custom Rules
DMZ
Status

^ General Settings

Enable Filtering ON OFF

Default Filtering Policy ?

^ Access Control Settings

Enable Remote SSH Access ON OFF

Enable Local SSH Access ON OFF

Enable Remote Telnet Access ON OFF

Enable Local Telnet Access ON OFF

Enable Remote HTTP Access ON OFF

Enable Local HTTP Access ON OFF

Enable Remote HTTPS Access ON OFF

Enable Remote Ping Respond ON OFF ?

Enable DOS Defending ON OFF

Enable Console ON OFF ?

Enable VPN NAT Traversal ON OFF ?

^ Whitelist Rules ?

| Index | Description | Source Address |
|-------|-------------|----------------|
| + | | |

^ Filtering Rules

| Index | Source Address | Source Port | Source MAC | Target Address | Target Port | Protocol |
|-------|----------------|-------------|------------|----------------|-------------|----------|
| + | | | | | | |

Click **+** to add the whitelist rules.

Filtering

^ Whitelist Rules

Index

Description

Source Address ?

Click **+** to add a filtering rule. The maximum count is 50. The window is displayed as below when defaulting “All”, “ICMP” or choosing “ICMPv6” as the protocol. Here take “All” as an example.

Filtering

^ Filtering Rules

| | |
|----------------|--------------------------------|
| Index | <input type="text" value="1"/> |
| Description | <input type="text"/> |
| Source Address | <input type="text"/> ? |
| Source MAC | <input type="text"/> ? |
| Target Address | <input type="text"/> ? |
| Protocol | All v |
| Action | Drop v |

The window is displayed as below when choosing “TCP”, “UDP” or “TCP-UDP” as the protocol. Here take “TCP” as an example.

^ Filtering Rules


| | |
|----------------|--------------------------------|
| Index | <input type="text" value="1"/> |
| Description | <input type="text"/> |
| Source Address | <input type="text"/> ? |
| Source Port | <input type="text"/> ? |
| Source MAC | <input type="text"/> ? |
| Target Address | <input type="text"/> ? |
| Target Port | <input type="text"/> ? |
| Protocol | TCP v |
| Action | Drop v |

| Filtering | | |
|--------------------------------|---|---------|
| Item | Description | Default |
| General Settings | | |
| Enable Filtering | Click the toggle button to enable/disable the filtering option. | ON |
| Default Filtering Policy | Select from “Accept” or “Drop”. Cannot be changed when filtering rules table is not empty. <ul style="list-style-type: none"> Accept: Router will accept all the connecting requests except the hosts which fit the drop filter list Drop: Router will drop all the connecting requests except the hosts which fit the accept filter list | Accept |
| Access Control Settings | | |
| Enable Remote SSH Access | Click the toggle button to enable/disable this option. When enabled, the Internet user can access the router remotely via SSH. | OFF |
| Enable Local SSH Access | Click the toggle button to enable/disable this option. When enabled, the LAN user can access the router locally via SSH. | ON |
| Enable Remote Telnet Access | Click the toggle button to enable/disable this option. When enabled, the Internet user can access the router remotely via Telnet. | OFF |

| Filtering | | |
|----------------------------|--|---------|
| Item | Description | Default |
| Enable Local Telnet Access | Click the toggle button to enable/disable this option. When enabled, the LAN user can access the router locally via Telnet. | ON |
| Enable Remote HTTP Access | Click the toggle button to enable/disable this option. When enabled, the Internet user can access the router remotely via HTTP. | OFF |
| Enable Local HTTP Access | Click the toggle button to enable/disable this option. When enabled, the LAN user can access the router locally via HTTP. | ON |
| Enable Remote HTTPS Access | Click the toggle button to enable/disable this option. When enabled, the Internet user can access the router remotely via HTTPS. | ON |
| Enable Remote Ping Respond | Click the toggle button to enable/disable this option. When enabled, the router will reply to the Ping requests from other hosts on the Internet. | ON |
| Enable DOS Defending | Click the toggle button to enable/disable this option. When enabled, the router will defend the DOS. Dos attack is an attempt to make a machine or network resource unavailable to its intended users. | ON |
| Enable debug port | Click the toggle button to enable / disable this option. | ON |
| Enable vpn nat traversal | Click the toggle button to enable / disable this option. When enabled, enable NAT traversal for GRE / L2TP / PPTP VPN packets. | OFF |
| Whitelist Rules | | |
| Index | Indicate the ordinal of the list. | -- |
| Description | Enter a description for this whitelist rule. | Null |
| Source Address | Specify an access originator and enter its source address. | Null |
| Filtering Rules | | |
| Index | Indicate the ordinal of the list. | -- |
| Description | Enter a description for this filtering rule. | Null |
| Source Address | Specify an access originator and enter its source address. | Null |
| Source Port | Specify an access originator and enter its source port. | Null |
| Source MAC | Specify an access originator and enter its source MAC address. | Null |
| Target Address | Enter the target address which the access originator wants to access. | Null |
| Target Port | Enter the target port which the access originator wants to access. | Null |
| Protocol | Select from "All", "TCP", "UDP", "ICMP", "ICMPv6" or "TCP-UDP". Note: It is recommended that you choose "All" if you don't know which protocol of your application to use. | All |
| Action | Select from "Accept" or "Drop". <ul style="list-style-type: none"> Accept: When Default Filtering Policy is drop, router will drop all the connecting requests except the hosts which fit this accept filtering list Drop: When Default Filtering Policy is accept, router will accept all the connecting requests except the hosts which fit this drop filtering list | Drop |

Port Mapping

Port mapping is defined manually in the router, and all data received from certain ports on the public network is forwarded to a certain port on a certain IP in the internal network. Click Network> Firewall> Port Mapping to display the following:



Click **+** to add port mapping rules. The maximum rule count is 40.

Port Mapping

^ Port Mapping Rules

Index:

Description:

Remote IP: ?

Internet Port: ?


Local IP:

Local Port: ?

Protocol: v

| Port Mapping Rules | | |
|--------------------|--|---------|
| Item | Description | Default |
| Index | Indicate the ordinal of the list. | -- |
| Description | Enter a description for this port mapping. | Null |
| Remote IP | Specify the host or network which can access the local IP address. Empty means unlimited, e.g. 10.10.10.10/255.255.255.255 or 192.168.1.0/24 | Null |
| Internet Port | Enter the internet port of router which can be accessed by other hosts from internet. | Null |
| Local IP | Enter router's LAN IP which will forward to the internet port of router. | Null |
| Local Port | Enter the port of router's LAN IP. | Null |
| Protocol | Select from "TCP", "UDP" or "TCP-UDP" as your application required. | TCP-UDP |

Custom rules, that is, rules that you define yourself. Click Network> Firewall> Custom Rule to display the following:



Click **+** to add an IPv4 or IPv6 custom rule, the window is displayed as follows (take "IPv4" as an example):

Custom Rules

^ Custom Iptables Rule

Index

Description

Rule ?

| Custom Firewall Rules | | |
|-----------------------|---|---------|
| Item | Description | Default |
| Index | Indicate the ordinal of the list. | -- |
| Description | Enter a description for this Custom Firewall Rules. | Null |
| Rule | Enter custom rules. | Null |

DMZ

DMZ (Demilitarized Zone), also known as the demilitarized zone. It is a buffer between a non-secure system and a secure system that is set up to solve the problem that users who access the external network cannot access the internal network server after the firewall is installed. A DMZ host is an intranet host where all ports are open to the specified address except the ports that are occupied and forwarded.

Click Network> Firewall> DMZ. The following information is displayed:

Filtering
Port Mapping
DMZ

^ DMZ Settings

Enable DMZ ON OFF

Host IP Address

Source IP Address ?

| DMZ Settings | | |
|-------------------|---|---------|
| Item | Description | Default |
| Enable DMZ | Click the toggle button to enable/disable DMZ. DMZ host is a host on the internal network that has all ports exposed, except those ports otherwise forwarded. | OFF |
| Host IP Address | Enter the IP address of the DMZ host on your internal network. | Null |
| Source IP Address | Set the address which can talk to the DMZ host. Null means for any addresses. | Null |

Click the Status bar to view the firewall status of the device.

| Filtering | Port Mapping | Custom Rules | DMZ | Status | | | |
|------------------------|--------------|--------------|----------|--------|-----|-----------|-------------|
| ^ Chain Input | | | | | | | |
| Index | Packets | Target | Protocol | In | Out | Source | Destination |
| 1 | 0 | DROP | tcp | wlan0 | * | 0.0.0.0/0 | 0.0.0.0/0 |
| 2 | 0 | DROP | tcp | wlan0 | * | 0.0.0.0/0 | 0.0.0.0/0 |
| 3 | 0 | DROP | tcp | wlan0 | * | 0.0.0.0/0 | 0.0.0.0/0 |
| 4 | 0 | REJECT | tcp | * | * | 0.0.0.0/0 | 0.0.0.0/0 |
| 5 | 6 | ACCEPT | tcp | * | * | 0.0.0.0/0 | 0.0.0.0/0 |
| 6 | 0 | DROP | tcp | * | * | 0.0.0.0/0 | 0.0.0.0/0 |
| 7 | 5 | ACCEPT | tcp | * | * | 0.0.0.0/0 | 0.0.0.0/0 |
| 8 | 0 | DROP | tcp | * | * | 0.0.0.0/0 | 0.0.0.0/0 |
| 9 | 0 | ACCEPT | icmp | * | * | 0.0.0.0/0 | 0.0.0.0/0 |
| 10 | 0 | DROP | icmp | * | * | 0.0.0.0/0 | 0.0.0.0/0 |
| 11 | 0 | DROP | tcp | wlan0 | * | ::/0 | ::/0 |
| 12 | 0 | DROP | tcp | wlan0 | * | ::/0 | ::/0 |
| 13 | 0 | DROP | tcp | wlan0 | * | ::/0 | ::/0 |
| 14 | 0 | REJECT | tcp | * | * | ::/0 | ::/0 |
| 15 | 0 | ACCEPT | tcp | * | * | ::/0 | ::/0 |
| 16 | 0 | DROP | tcp | * | * | ::/0 | ::/0 |
| 17 | 0 | ACCEPT | tcp | * | * | ::/0 | ::/0 |
| 18 | 0 | DROP | tcp | * | * | ::/0 | ::/0 |
| 19 | 0 | ACCEPT | icmpv6 | * | * | ::/0 | ::/0 |
| 20 | 0 | DROP | icmpv6 | * | * | ::/0 | ::/0 |
| ^ Chain Forward | | | | | | | |
| Index | Packets | Target | Protocol | In | Out | Source | Destination |
| 1 | 0 | TCPMSS | tcp | * | * | 0.0.0.0/0 | 0.0.0.0/0 |
| 2 | 0 | TCPMSS | tcp | * | * | ::/0 | ::/0 |
| ^ Chain Output | | | | | | | |
| Index | Packets | Target | Protocol | In | Out | Source | Destination |

3.13 Network > IP Passthrough

Click **Network > IP Passthrough > IP Passthrough** to enable or disable the IP Pass-through option.



If router enables the IP Pass-through, the terminal device (such as PC) will enable the DHCP Client mode and connect to LAN port of the router; and after the router dial up successfully, the PC will automatically obtain the IP address and DNS server address which assigned by ISP.

3.14 VPN > IPsec

This section allows you to set the IPsec and the related parameters. Internet Protocol Security (IPsec) is a protocol suite for secure Internet Protocol (IP) communications that works by authenticating and encrypting each IP packet of

a communication session.

Click **Virtual Private Network> IPsec> General** to set IPsec parameters.

General

| General Settings @ General | | |
|----------------------------|--|---------|
| Item | Description | Default |
| Enable NAT Traversal | Click the toggle button to enable/disable the NAT Traversal function. This option must be enabled when router under NAT environment. | ON |
| Keepalive | Set the keepalive time, measured in seconds. The router will send packets to NAT server every keepalive time to avoid record remove from the NAT list. | 60 |
| Debug Enable | Click the toggle button to enable/disable this option. Enable for IPsec VPN information output to the debug port. | OFF |

Tunnel

Click **+** to add tunnel settings. The maximum count is 3.

| General Settings @ Tunnel | | |
|---------------------------|--|-----------|
| Item | Description | Default |
| Index | Indicate the ordinal of the list. | -- |
| Enable | Click the toggle button to enable/disable this IPsec tunnel. | ON |
| Description | Enter a description for this IPsec tunnel. | Null |
| Gateway | Enter the address or domain name of remote side IPsec VPN server. 0.0.0.0 represents for any address. | Null |
| Mode | Select from "Tunnel" and "Transport". <ul style="list-style-type: none"> Tunnel: Commonly used between gateways, or at an end-station to a gateway, the gateway acting as a proxy for the hosts behind it Transport: Used between end-stations or between an end-station and a gateway, if the gateway is being treated as a host-for example, an encrypted Telnet session from a workstation to a router, in which the router is the actual destination | Tunnel |
| Protocol | Select the security protocols from "ESP" and "AH". <ul style="list-style-type: none"> ESP: Use the ESP protocol AH: Use the AH protocol | ESP |
| Local Subnet | Enter the local subnet's address with mask protected by IPsec, e.g. 192.168.1.0/24 | Null |
| Remote Subnet | Enter the remote subnet's address with mask protected by IPsec, e.g. 10.8.0.0/24 | Null |
| Link binding | Select from WWAN1, WWAN2, WAN, or WLAN. | Not bound |


The window is displayed as below when choosing “PSK” as the authentication type.



The screenshot shows the 'IKE Settings' window with the following configuration:

| Setting | Value |
|--------------------------|----------|
| IKE Type | IKEv1 |
| Negotiation Mode | Main |
| Encryption Algorithm | 3DES |
| Authentication Algorithm | SHA1 |
| IKE DH Group | DHgroup2 |
| Authentication Type | PSK |
| PSK Secret | |
| Local ID Type | Default |
| Remote ID Type | Default |
| IKE Lifetime | 86400 |

The window is displayed as below when choosing “CA” as the authentication type.



The screenshot shows the 'IKE Settings' window with the following configuration:

| Setting | Value |
|--------------------------|----------|
| IKE Type | IKEv1 |
| Negotiation Mode | Main |
| Encryption Algorithm | 3DES |
| Authentication Algorithm | SHA1 |
| IKE DH Group | DHgroup2 |
| Authentication Type | CA |
| Private Key Password | |
| IKE Lifetime | 86400 |

The window is displayed as below when choosing “PKCS#12” as the authentication type.



The screenshot shows the 'IKE Settings' window with the following configuration:

| Setting | Value |
|--------------------------|----------|
| IKE Type | IKEv1 |
| Negotiation Mode | Main |
| Encryption Algorithm | 3DES |
| Authentication Algorithm | SHA1 |
| IKE DH Group | DHgroup2 |
| Authentication Type | PKCS#12 |
| Private Key Password | |
| IKE Lifetime | 86400 |

The window is displayed as below when choosing “xAuth PSK” as the authentication type.

^ IKE Settings

| | | |
|--------------------------|----------------------|---|
| IKE Type | IKEv1 | v |
| Negotiation Mode | Main | v |
| Encryption Algorithm | 3DES | v |
| Authentication Algorithm | SHA1 | v |
| IKE DH Group | DHgroup2 | v |
| Authentication Type | xAuth PSK | v |
| PSK Secret | <input type="text"/> | |
| Local ID Type | Default | v |
| Remote ID Type | Default | v |
| Username | <input type="text"/> | ? |
| Password | <input type="text"/> | ? |
| IKE Lifetime | 86400 | ? |

The window is displayed as below when choosing “xAuth CA” as the authentication type.

^ IKE Settings

| | | |
|--------------------------|----------------------|---|
| IKE Type | IKEv1 | v |
| Negotiation Mode | Main | v |
| Encryption Algorithm | 3DES | v |
| Authentication Algorithm | SHA1 | v |
| IKE DH Group | DHgroup2 | v |
| Authentication Type | xAuth CA | v |
| Private Key Password | <input type="text"/> | |
| Username | <input type="text"/> | ? |
| Password | <input type="text"/> | ? |
| IKE Lifetime | 86400 | ? |

| IKE Settings | | |
|--------------------------|---|---------|
| Item | Description | Default |
| IKE Type | Select from "IKEv1" and "IKEv2". | IKEv1 |
| Negotiation Mode | Select from “Main” and “Aggressive” for the IKE negotiation mode in phase 1. If the IP address of one end of an IPsec tunnel is obtained dynamically, the IKE negotiation mode must be aggressive. In this case, SAs can be established as long as the username and password are correct. | Main |
| Authentication Algorithm | Select from “MD5”, “SHA1”, “SHA2 256” or “SHA2 512” to be used in IKE negotiation. | SHA1 |
| Encrypt Algorithm | Select from “3DES”, “AES128”, “AES192” and “AES256”to be used in IKE negotiation. | 3DES |

| IKE Settings | | |
|----------------------|--|----------|
| Item | Description | Default |
| | <ul style="list-style-type: none"> 3DES: Use 168-bit 3DES encryption algorithm in CBC mode AES128: Use 128-bit AES encryption algorithm in CBC mode AES256: Use 256-bit AES encryption algorithm in CBC mode | |
| IKE DH Group | Select from "DHgroup1", "DHgroup2", "DHgroup5", "DHgroup14", "DHgroup15", "DHgroup16", "DHgroup17" or "DHgroup18" to be used in key negotiation phase 1. | DHgroup2 |
| Authentication Type | Select from "PSK", "CA", "PKCS#12", "xAuth PSK" and "xAuth CA" to be used in IKE negotiation. <ul style="list-style-type: none"> PSK: Pre-shared Key CA: x509 Certificate Authority xAuth: Extended Authentication to AAA server | PSK |
| PSK Secret | Enter the pre-shared key. | Null |
| Local ID Type | Select from "Default", "FQDN" and "User FQDN" for IKE negotiation. <ul style="list-style-type: none"> Default: Use an IP address as the ID in IKE negotiation FQDN: Use an FQDN type as the ID in IKE negotiation. If this option is selected, type a name without any at sign (@) for the local security gateway, e.g., test.robustel.com. User FQDN: Use a user FQDN type as the ID in IKE negotiation. If this option is selected, type a name string with a sign "@" for the local security gateway, e.g., test@robustel.com. | Default |
| Remote ID Type | Select from "Default", "FQDN" and "User FQDN" for IKE negotiation. <ul style="list-style-type: none"> Default: Use an IP address as the ID in IKE negotiation FQDN: Use an FQDN type as the ID in IKE negotiation. If this option is selected, type a name without any at sign (@) for the local security gateway, e.g., test.robustel.com. User FQDN: Use a user FQDN type as the ID in IKE negotiation. If this option is selected, type a name string with a sign "@" for the local security gateway, e.g., test@robustel.com. | Default |
| IKE Lifetime | Set the lifetime in IKE negotiation. Before an SA expires, IKE negotiates a new SA. As soon as the new SA is set up, it takes effect immediately and the old one will be cleared automatically when it expires. | 86400 |
| Private Key Password | Enter the private key under the "CA" and "xAuth CA" authentication types. | Null |
| Username | Enter the username used for the "xAuth PSK" and "xAuth CA" authentication types. | Null |
| Password | Enter the password used for the "xAuth PSK" and "xAuth CA" authentication types. | Null |

If click **VPN > IPsec > Tunnel > General Settings**, and choose **ESP** as protocol. The specific parameter configuration is shown as below.

^ General Settings

| | |
|---------------|---|
| Index | <input type="text" value="1"/> |
| Enable | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Description | <input type="text"/> |
| Gateway | <input type="text"/> ? |
| Mode | <input type="text" value="Tunnel"/> v |
| Protocol | <input type="text" value="ESP"/> v |
| Local Subnet | <input type="text"/> ? |
| Remote Subnet | <input type="text"/> ? |
| Link Binding | <input type="text" value="Unspecified"/> v ? |

^ IKE Settings

^ SA Settings

| | |
|--------------------------|---|
| Encryption Algorithm | <input type="text" value="3DES"/> v |
| Authentication Algorithm | <input type="text" value="SHA1"/> v |
| PFS Group | <input type="text" value="DHgroup2"/> v |
| SA Lifetime | <input type="text" value="28800"/> ? |
| DPD Interval | <input type="text" value="30"/> ? |
| DPD Failures | <input type="text" value="150"/> ? |

If choose **AH** as protocol, the window of SA Settings is displayed as below.

^ General Settings

| | |
|---------------|---|
| Index | <input type="text" value="1"/> |
| Enable | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Description | <input type="text"/> |
| Gateway | <input type="text"/> ? |
| Mode | <input type="text" value="Tunnel"/> v |
| Protocol | <input type="text" value="AH"/> v |
| Local Subnet | <input type="text"/> ? |
| Remote Subnet | <input type="text"/> ? |
| Link Binding | <input type="text" value="Unspecified"/> v ? |

^ IKE Settings

^ SA Settings

Authentication Algorithm v

PFS Group v

SA Lifetime ?

DPD Interval ?

DPD Failures ?

^ Advanced Settings

Enable Compression OFF ?

Enable Forceencaps OFF ?

Expert Options ?

| SA Settings | | |
|-----------------------------|---|----------|
| Item | Description | Default |
| Encrypt Algorithm | Select from “3DES”, “AES128” or “AES256” when you select “ESP” in “Protocol”. Higher security means more complex implementation and lower speed. DES is enough to meet general requirements. Use 3DES when high confidentiality and security are required. | 3DES |
| Authentication Algorithm | Select from “MD5”, “SHA1”, “SHA2 256” or “SHA2 512” to be used in SA negotiation. | MD5 |
| PFS Group | Select from “DHgroup1”, “DHgroup2”, “DHgroup5”, “DHgroup14”, “DHgroup15”, “DHgroup16”, “DHgroup17” or “DHgroup18” to be used in SA negotiation. | DHgroup2 |
| SA Lifetime | Set the IPsec SA lifetime. When negotiating set up IPsec SAs, IKE uses the smaller one between the lifetime set locally and the lifetime proposed by the peer. | 28800 |
| DPD Interval | Set the interval after which DPD is triggered if no IPsec protected packets is received from the peer. DPD is Dead peer detection. DPD irregularly detects dead IKE peers. When the local end sends an IPsec packet, DPD checks the time the last IPsec packet was received from the peer. If the time exceeds the DPD interval, it sends a DPD hello to the peer. If the local end receives no DPD acknowledgment within the DPD packet retransmission interval, it retransmits the DPD hello. If the local end still receives no DPD acknowledgment after having made the maximum number of retransmission attempts, it considers the peer already dead, and clears the IKE SA and the IPsec SAs based on the IKE SA. | 60 |
| DPD Failures | Set the timeout of DPD (Dead Peer Detection) packets. | 180 |
| Advanced Settings | | |
| Enable Compression | Click the toggle button to enable/disable this option. Enable to compress the inner headers of IP packets. | OFF |
| Enable Forced Encapsulation | Click the toggle button to enable / disable this option. After it is enabled, even if no NAT condition is detected, the UDP encapsulation of esp packets is forced. This may help overcome restrictive firewalls. | OFF |

| SA Settings | | |
|----------------|--|---------|
| Item | Description | Default |
| Expert Options | Add more PPP configuration options here, format: config-desc;config-desc, e.g. protostack=netkey;plutodebug=none | Null |

Status

This section allows you to view the status of the IPsec tunnel.

x509

User can upload the X509 certificates for the IPsec tunnel in this section.

| x509 | | |
|----------------------|---|----------|
| Item | Description | Default |
| X509 Settings | | |
| Tunnel Name | Choose a valid tunnel. | Tunnel 1 |
| Certificate Files | Click on “Choose File” to locate the certificate file from your computer, and then import this file into your router. The correct file format is displayed as follows: @ca.crt @remote.crt @local.crt @private.key @crl.pem | -- |
| Peer Certificate | Select the peer certificate to import to the router. | -- |
| Private Key | Select the correct private key file to import into the router. | -- |
| Root Certificate | Select the root certificate file to import into the router. | -- |

| x509 | | |
|-----------------------|--|---------|
| Item | Description | Default |
| PKCS # 12 Certificate | Select the PKCS # 12 certificate file to import into the route | -- |
| Certificate Files | | |
| Index | Indicate the ordinal of the list. | -- |
| Filename | Show the imported certificate's name. | Null |
| File Size | Show the size of the certificate file. | Null |
| Last Modification | Show the timestamp of that the last time to modify the certificate file. | Null |

3.15 VPN > OpenVPN

This section allows you to set the OpenVPN and the related parameters. OpenVPN is an open-source software application that implements virtual private network (VPN) techniques for creating secure point-to-point or site-to-site connections in routed or bridged configurations and remote access facilities. Router supports point-to-point and point-to-points connections.

Click **Virtual Private Network > OpenVPN > OpenVPN**. The following information is displayed:

OpenVPN

| OpenVPN | Status | x509 | | | | | |
|-------------------|--------|-------------|------|----------|----------------|----------------|---|
| ^ Tunnel Settings | | | | | | | |
| Index | Enable | Description | Mode | Protocol | Server Address | Interface Type | + |

Click **+** to add tunnel settings. The maximum count is 3. The window is displayed as below when choosing "None" as the authentication type. By default, the mode is "P2P".

OpenVPN

^ General Settings

Index

Enable ON OFF

Enable IPv6 ON OFF

Description

Mode

TLS Mode

Protocol

Peer Address

Peer Port

Listen IP Address

Listen Port

Interface Type

Authentication Type

Local IP

Remote IP

Encrypt Algorithm

Authentication Algorithm

Keepalive Interval

Keepalive Timeout

TUN MTU

Max Frame Size

Enable Compression ON OFF

Enable NAT ON OFF

Verbose Level

The window is displayed as below when choosing "Client" as the mode.

General Settings

| | |
|--------------------------|---|
| Index | <input type="text" value="1"/> |
| Enable | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Description | <input type="text"/> |
| Mode | <input type="text" value="Client"/> v ? |
| Protocol | <input type="text" value="UDP"/> v |
| Peer Address | <input type="text"/> |
| Peer Port | <input type="text" value="1194"/> |
| Interface Type | <input type="text" value="TUN"/> v |
| Authentication Type | <input type="text" value="None"/> v ? |
| Encrypt Algorithm | <input type="text" value="BF"/> v |
| Authentication Algorithm | <input type="text" value="SHA1"/> v |
| Renegotiation Interval | <input type="text" value="86400"/> ? |
| Keepalive Interval | <input type="text" value="20"/> ? |
| Keepalive Timeout | <input type="text" value="120"/> ? |
| TUN MTU | <input type="text" value="1500"/> |
| Max Frame Size | <input type="text"/> |
| Enable Compression | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable NAT | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Enable DNS overrid | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF ? |
| Verbose Level | <input type="text" value="0"/> v ? |

The window is displayed as below when choosing “Server” as the mode.

^ General Settings

| | |
|--------------------------|---|
| Index | <input type="text" value="1"/> |
| Enable | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable IPv6 | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Description | <input type="text"/> |
| Mode | <input type="text" value="Server"/> <input type="button" value="v"/> <input type="button" value="?"/> |
| Protocol | <input type="text" value="UDP"/> <input type="button" value="v"/> |
| Listen IP Address | <input type="text"/> |
| Listen Port | <input type="text" value="1194"/> |
| Interface Type | <input type="text" value="TUN"/> <input type="button" value="v"/> |
| Authentication Type | <input type="text" value="None"/> <input type="button" value="v"/> <input type="button" value="?"/> |
| Enable IP Pool | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Client Subnet | <input type="text" value="10.8.0.0"/> |
| Client Subnet Netmask | <input type="text" value="255.255.255.0"/> |
| Encrypt Algorithm | <input type="text" value="BF"/> <input type="button" value="v"/> |
| Authentication Algorithm | <input type="text" value="SHA1"/> <input type="button" value="v"/> |
| Renegotiation Interval | <input type="text" value="86400"/> <input type="button" value="?"/> |
| Max Clients | <input type="text" value="10"/> |
| Keepalive Interval | <input type="text" value="20"/> <input type="button" value="?"/> |
| Keepalive Timeout | <input type="text" value="120"/> <input type="button" value="?"/> |
| TUN MTU | <input type="text" value="1500"/> |
| Max Frame Size | <input type="text"/> |
| Private Key Password | <input type="text"/> |
| Enable Compression | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable Default Gateway | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Enable NAT | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Verbose Level | <input type="text" value="0"/> <input type="button" value="v"/> <input type="button" value="?"/> |

The window is displayed as below when choosing “None” as the authentication type.

General Settings

| | |
|----------------------------|---|
| Index | <input type="text" value="1"/> |
| Enable | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable IPv6 | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Description | <input type="text"/> |
| Mode | <input type="text" value="P2P"/> <input type="button" value="v"/> <input type="button" value="?"/> |
| TLS Mode | <input type="text" value="None"/> <input type="button" value="v"/> <input type="button" value="?"/> |
| Protocol | <input type="text" value="UDP"/> <input type="button" value="v"/> |
| Peer Address | <input type="text"/> |
| Peer Port | <input type="text" value="1194"/> |
| Listen IP Address | <input type="text"/> |
| Listen Port | <input type="text" value="1194"/> |
| Interface Type | <input type="text" value="TUN"/> <input type="button" value="v"/> |
| Authentication Type | <input type="text" value="None"/> <input type="button" value="v"/> <input type="button" value="?"/> |
| Local IP | <input type="text" value="10.8.0.1"/> |
| Remote IP | <input type="text" value="10.8.0.2"/> |
| Encrypt Algorithm | <input type="text" value="BF"/> <input type="button" value="v"/> |
| Authentication Algorithm | <input type="text" value="SHA1"/> <input type="button" value="v"/> |
| Keepalive Interval | <input type="text" value="20"/> <input type="button" value="?"/> |
| Keepalive Timeout | <input type="text" value="120"/> <input type="button" value="?"/> |
| TUN MTU | <input type="text" value="1500"/> |
| Max Frame Size | <input type="text"/> |
| Enable Compression | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable NAT | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Verbose Level | <input type="text" value="0"/> <input type="button" value="v"/> <input type="button" value="?"/> |

The window is displayed as below when choosing “Preshared” as the authentication type.

^ General Settings

| | |
|----------------------------|---|
| Index | <input type="text" value="1"/> |
| Enable | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable IPv6 | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Description | <input type="text"/> |
| Mode | <input type="text" value="P2P"/> v ? |
| TLS Mode | <input type="text" value="None"/> v ? |
| Protocol | <input type="text" value="UDP"/> v |
| Peer Address | <input type="text"/> |
| Peer Port | <input type="text" value="1194"/> |
| Listen IP Address | <input type="text"/> |
| Listen Port | <input type="text" value="1194"/> |
| Interface Type | <input type="text" value="TUN"/> v |
| Authentication Type | <input type="text" value="Preshared"/> v ? |
| Local IP | <input type="text" value="10.8.0.1"/> |
| Remote IP | <input type="text" value="10.8.0.2"/> |
| Encrypt Algorithm | <input type="text" value="BF"/> v |
| Authentication Algorithm | <input type="text" value="SHA1"/> v |
| Keepalive Interval | <input type="text" value="20"/> ? |
| Keepalive Timeout | <input type="text" value="120"/> ? |
| TUN MTU | <input type="text" value="1500"/> |
| Max Frame Size | <input type="text"/> |
| Enable Compression | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable NAT | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Verbose Level | <input type="text" value="0"/> v ? |

The window is displayed as below when choosing “Password” as the authentication type.

^ General Settings

| | |
|--------------------------|---|
| Index | <input type="text" value="1"/> |
| Enable | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable IPv6 | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Description | <input type="text"/> |
| Mode | <input type="text" value="P2P"/> <input type="button" value="v"/> <input type="button" value="?"/> |
| TLS Mode | <input type="text" value="None"/> <input type="button" value="v"/> <input type="button" value="?"/> |
| Protocol | <input type="text" value="UDP"/> <input type="button" value="v"/> |
| Peer Address | <input type="text"/> |
| Peer Port | <input type="text" value="1194"/> |
| Listen IP Address | <input type="text"/> |
| Listen Port | <input type="text" value="1194"/> |
| Interface Type | <input type="text" value="TUN"/> <input type="button" value="v"/> |
| Authentication Type | <input type="text" value="Password"/> <input type="button" value="v"/> <input type="button" value="?"/> |
| Local IP | <input type="text" value="10.8.0.1"/> |
| Remote IP | <input type="text" value="10.8.0.2"/> |
| Encrypt Algorithm | <input type="text" value="BF"/> <input type="button" value="v"/> |
| Authentication Algorithm | <input type="text" value="SHA1"/> <input type="button" value="v"/> |
| Keepalive Interval | <input type="text" value="20"/> <input type="button" value="?"/> |
| Keepalive Timeout | <input type="text" value="120"/> <input type="button" value="?"/> |
| TUN MTU | <input type="text" value="1500"/> |
| Max Frame Size | <input type="text"/> |
| Enable Compression | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable NAT | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Verbose Level | <input type="text" value="0"/> <input type="button" value="v"/> <input type="button" value="?"/> |

The window is displayed as below when choosing “X509CA” as the authentication type.

^ General Settings

| | |
|--------------------------|---|
| Index | <input type="text" value="1"/> |
| Enable | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable IPv6 | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Description | <input type="text"/> |
| Mode | <input type="text" value="P2P"/> v ⓘ |
| TLS Mode | <input type="text" value="None"/> v ⓘ |
| Protocol | <input type="text" value="UDP"/> v |
| Peer Address | <input type="text"/> |
| Peer Port | <input type="text" value="1194"/> |
| Listen IP Address | <input type="text"/> |
| Listen Port | <input type="text" value="1194"/> |
| Interface Type | <input type="text" value="TUN"/> v |
| Authentication Type | <input type="text" value="X509CA"/> v ⓘ |
| Local IP | <input type="text" value="10.8.0.1"/> |
| Remote IP | <input type="text" value="10.8.0.2"/> |
| Encrypt Algorithm | <input type="text" value="BF"/> v |
| Authentication Algorithm | <input type="text" value="SHA1"/> v |
| Keepalive Interval | <input type="text" value="20"/> ⓘ |
| Keepalive Timeout | <input type="text" value="120"/> ⓘ |
| TUN MTU | <input type="text" value="1500"/> |
| Max Frame Size | <input type="text"/> |
| Private Key Password | <input type="text"/> |
| Enable Compression | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable NAT | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Verbose Level | <input type="text" value="0"/> v ⓘ |

The window is displayed as below when choosing “X509CA Password” as the authentication type.

^ General Settings

| | |
|--------------------------|---|
| Index | <input type="text" value="1"/> |
| Enable | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable IPv6 | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Description | <input type="text"/> |
| Mode | <input type="text" value="P2P"/> ? |
| TLS Mode | <input type="text" value="None"/> ? |
| Protocol | <input type="text" value="UDP"/> |
| Peer Address | <input type="text"/> |
| Peer Port | <input type="text" value="1194"/> |
| Listen IP Address | <input type="text"/> |
| Listen Port | <input type="text" value="1194"/> |
| Interface Type | <input type="text" value="TUN"/> |
| Authentication Type | <input type="text" value="X509CA Password"/> ? |
| Local IP | <input type="text" value="10.8.0.1"/> |
| Remote IP | <input type="text" value="10.8.0.2"/> |
| Encrypt Algorithm | <input type="text" value="BF"/> |
| Authentication Algorithm | <input type="text" value="SHA1"/> |
| Keepalive Interval | <input type="text" value="20"/> ? |
| Keepalive Timeout | <input type="text" value="120"/> ? |
| TUN MTU | <input type="text" value="1500"/> |
| Max Frame Size | <input type="text"/> |
| Private Key Password | <input type="text"/> |
| Enable Compression | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Enable NAT | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Verbose Level | <input type="text" value="0"/> ? |

^ Advanced Settings

The window is displayed as below when choosing “Client” as the mode.

^ Advanced Settings

| | |
|----------------------|---|
| Enable HMAC Firewall | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Enable PKCS#12 | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Enable nsCertType | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Expert Options | <input type="text"/> ? |

The window is displayed as below when choosing “Server” as the mode.

^ **Advanced Settings**

Enable HMAC Firewall
 OFF

Enable Cri
 OFF

Enable Client To Client
 OFF

Enable Dup Client
 OFF

Enable IP Persist
 ON OFF ?

Expert Options
 ?

The window of "Virtual Private Network> OpenVPN> OpenVPN" is displayed as below when choosing "Server" as the mode and choosing "X509CA Password" as the authentication type.

^ **OpenVPN**

Status
x509

^ **Tunnel Settings**

| Index | Enable | Description | Mode | Protocol | Peer Address | Interface Type | + |
|-------|--------|-------------|------|----------|--------------|----------------|---|
| | | | | | | | |

^ **Password Manage**

| Index | Username | + |
|-------|----------|---|
| | | |

^ **Client Manage**

| Index | Enable | Common Name | Client IP Address | + |
|-------|--------|-------------|-------------------|---|
| | | | | |

Click User Password Management + to add username and password, as shown below:

^ **OpenVPN**

^ **General Settings**

Index

Username

Password

Click Client Management + to add client information, as shown below:

^ **OpenVPN**

^ **General Settings**

Index

Enable
 ON OFF

Common Name
 ?

Client IP Address

| General Settings @ OpenVPN | | |
|----------------------------|---|---------|
| Item | Description | Default |
| Index | Indicate the ordinal of the list. | -- |
| Enable | Click the toggle button to enable/disable this OpenVPN tunnel. | ON |
| Enable Ipv6 | Click the toggle button to enable / disable OpenVPN using IPv6. | OFF |
| Description | Enter a description for this OpenVPN tunnel. | Null |

| General Settings @ OpenVPN | | |
|----------------------------|--|---------------|
| Item | Description | Default |
| Mode | Select from "P2P" or "Client". | Client |
| TLS Mode | Select from "None", "Client" or "Server". | None |
| Protocol | Select from "UDP", "TCP-Client" or "TCP-Server". | UDP |
| Server Address | Enter the end-to-end IP address or the domain of the remote OpenVPN server. | Null |
| Server Port | Enter the end-to-end listener port or the listening port of the OpenVPN server. | 1194 |
| Listening Address | Local server address. | Null |
| Listening Port | Local server port. | 1194 |
| Interface Type | Select from "TUN" or "TAP" which are two different kinds of device interface for OpenVPN. The difference between TUN and TAP device is that a TUN device is a point-to-point virtual device on network while a TAP device is a virtual device on Ethernet. | TUN |
| Authentication Type | Select from "None", "Preshared", "Password", "X509CA" and "X509CA Password". Note: "None" and "Preshared" authentication type are only working with P2P mode. | None |
| Enable IP Address Pool | Click the toggle button to enable / disable the IP address pool allocation function. | OFF |
| Starting Address | Defines the beginning of an IP address pool that assigns addresses to OpenVPN clients. | 10.8.0.5 |
| End Address | Defines the end of the IP address pool for assigning addresses to OpenVPN clients. | 10.8.0.254 |
| Client Network | Enter the client network IP. | 10.8.0.0 |
| Client Netmask | Enter the client netmask. | 255.255.255.0 |
| Username | Enter the username used for "Password" or "X509CA Password" authentication type. | Null |
| Password | Enter the password used for "Password" or "X509CA Password" authentication type. | Null |
| Local IP | Enter the local virtual IP. | 10.8.0.1 |
| Remote IP | Enter the remote virtual IP. | 10.8.0.2 |
| Encrypt Algorithm | Select from "BF", "DES", "DES-EDE3", "AES128", "AES192" and "AES256". <ul style="list-style-type: none"> BF: Use 128-bit BF encryption algorithm in CBC mode DES: Use 64-bit DES encryption algorithm in CBC mode DES-EDE3: Use 192-bit 3DES encryption algorithm in CBC mode AES128: Use 128-bit AES encryption algorithm in CBC mode AES192: Use 192-bit AES encryption algorithm in CBC mode AES256: Use 256-bit AES encryption algorithm in CBC mode | BF |
| Renegotiation Interval | Set the renegotiation interval. If connection failed, OpenVPN will renegotiate when the renegotiation interval reached. | 86400 |

| General Settings @ OpenVPN | | |
|-----------------------------|---|---------|
| Item | Description | Default |
| Maximum Number of Clients | Set the maximum number of clients allowed to access the OpenVPN server. | 10 |
| Keepalive Interval | Set keepalive (ping) interval to check if the tunnel is active. | 20 |
| Keepalive Timeout | Set the keepalive timeout. Trigger OpenVPN restart after n seconds pass without reception of a ping or other packet from remote. | 120 |
| MTU | Set the maximum transmission unit. | 1500 |
| Data Fragmentation | Set the maximum frame length. | Null |
| Private Key Password | Enter the private key password under the "X509CA" and "X509CA Password" authentication type. | Null |
| Enable Compression | Click the toggle button to enable/disable this option. Enable to compress the data stream of the header. | ON |
| Enable Default Gateway | Standalone switch button to enable / disable the default gateway function. After enabling, push the local tunnel address as the default gateway of the peer device. | OFF |
| Receive DNS Push | Standalone switch button to enable / disable receiving DNS push function. After enabling, it is allowed to receive DNS information pushed by the peer. | OFF |
| Enable NAT | Click the toggle button to enable/disable the NAT option. When enabled, the source IP address of host behind router will be disguised before accessing the remote OpenVPN client. | OFF |
| Verbose Level | Select the level of the output log and values from 0 to 11. <ul style="list-style-type: none"> 0: No output except fatal errors 1~4: Normal usage range 5: Output R and W characters to the console for each packet read and write 6~11: Debug info range | 0 |
| Advanced Settings @ OpenVPN | | |
| Enable HMAC Firewall | Click the toggle button to enable/disable this option. Add an additional layer of HMAC authentication on top of the TLS control channel to protect against DoS attacks. | OFF |
| Enable PKCS#12 | Click the toggle button to enable/disable the PKCS#12 certificate. It is an exchange of digital certificate encryption standard, used to describe personal identity information. | OFF |
| Enable nsCertType | Click the toggle button to enable/disable nsCertType. Require that peer certificate was signed with an explicit nsCertType designation of "server". | OFF |
| Enable Crl | Click the toggle button to enable / disable the option. When enabled, client certificates can be revoked. | OFF |
| Enable Client to Client | Click the toggle button to enable / disable the option. When enabled, clients can communicate with each other. | OFF |

| General Settings @ OpenVPN | | |
|--|--|---------|
| Item | Description | Default |
| Enable Dup Client | Click the toggle button to enable / disable the option. After being enabled, the tunnel IPs obtained by multiple clients are different, and the tunnel IP of the client and the tunnel IP of the server are interoperable. | OFF |
| Enable IP Address Hold | Click the toggle button to enable / disable the option. When enabled, the IP in the address pool is obtained automatically. | ON |
| Expert Options | Enter some other options of OpenVPN in this field. Each expression can be separated by a ';'. | Null |
| Advanced Settings @ User Password Management | | |
| Username | Custom tunnel connection username. | Null |
| Password | Custom tunnel connection password. | Null |
| Client Management | | |
| Enable | Click the toggle button to enable / disable this option. When enabled, the client IP address can be managed. | OFF |
| Common Name | Set the certificate name. | Null |
| Client IP Address | Set a fixed client virtual IP. | Null |

Status

This section allows you to view the status of the OpenVPN tunnel.

| OpenVPN | Status | x509 | | | | |
|-------------------------|-------------|---------|------|------------|--------------|------------|
| ^ OpenVPN Tunnel Status | | | | | | |
| Index | Description | Status | Mode | Uptime | Local IP | Local IPv6 |
| ^ OpenVPN Client List | | | | | | |
| Index | Common Name | Real IP | Port | Virtual IP | Virtual IPv6 | |

x509

User can upload the X509 certificates for the OpenVPN in this section.

OpenVPN
Status
x509

^ X509 Settings
?

Tunnel Name

Mode

Root CA No file chosen

Certificate File No file chosen

Private Key No file chosen

TLS-Auth Key No file chosen

PKCS#12 Certificate No file chosen

^ Certificate Files

| Index | File Name | File Size | Modification Time |
|-------|-----------|-----------|-------------------|
|-------|-----------|-----------|-------------------|

| x509 | | |
|--------------------------|---|-------------|
| Item | Description | Default |
| X509 Settings | | |
| Tunnel Name | Choose a valid tunnel. Select from "Tunnel 1", "Tunnel 2", "Tunnel 3", "Tunnel 4", "Tunnel 5" or "Tunnel 6". | Tunnel 1 |
| Tunnel mode | Select "P2P Mode", "Client Mode" or "Server Mode". | Client mode |
| Root certificate | Select the root certificate file to import into the router. | -- |
| Certificate Files | Click on "Choose File" to locate the certificate file from your computer, and then import this file into your router. | -- |
| Private Key | Select the private key file to import into the router. | -- |
| TLS-Auth Key | Select the TLS-Auth key file to import into the router. | -- |
| PKCS # 12 Certificate | Select the PKCS # 12 certificate file to import into the router. | -- |
| Certificate Files | | |
| Index | Indicate the ordinal of the list. | -- |
| Filename | Show the imported certificate's name. | Null |
| File Size | Show the size of the certificate file. | Null |
| Last Modification | Show the timestamp of that the last time to modify the certificate file. | Null |

3.16 VPN > GRE

This section allows you to set the GRE and the related parameters. Generic Routing Encapsulation (GRE) is a tunneling protocol that can encapsulate a wide variety of network layer protocols inside virtual point-to-point links over an Internet Protocol network. There are two main uses of the GRE protocol: enterprise internal protocol encapsulation and private address encapsulation.

GRE

GRE Status

^ Tunnel Settings

| Index | Enable | Description | Remote IP Address |
|-------|--------|-------------|-------------------|
| | | | |

+

Click **+** to add tunnel settings. The maximum count is 3.

GRE

^ Tunnel Settings

Index

Enable ON OFF

Description

Remote IP Address

Local Virtual IP Address

Local Virtual Netmask/Prefix Length

Remote Virtual IP Address

Enable Default Route ON OFF

Enable NAT ON OFF

Secrets

Link Binding

| Tunnel Settings @ GRE | | |
|--|--|-----------|
| Item | Description | Default |
| Index | Indicate the ordinal of the list. | -- |
| Enable | Click the toggle button to enable/disable this GRE tunnel. | ON |
| Description | Enter a description for this GRE tunnel. | Null |
| Remote IP Address | Set the remote real IP address of the GRE tunnel. | Null |
| Local Virtual IP Address | Set the local virtual IP address of the GRE tunnel. | Null |
| Local Virtual Netmask/IPv6 prefix length | Set the local virtual Netmask of the GRE tunnel. | Null |
| Remote Virtual IP Address | Set the remote virtual IP Address of the GRE tunnel. | Null |
| Enable Default Route | Click the toggle button to enable/disable this option. When enabled, all the traffics of the router will go through the GRE VPN. | OFF |
| Enable NAT | Click the toggle button to enable/disable this option. This option must be enabled when router under NAT environment. | OFF |
| Secrets | Set the key of the GRE tunnel. | Null |
| Link Binding | Select from "WWAN1", "WWAN2", "WAN", or "WLAN". | Not bound |

Status

This section allows you to view the status of GRE tunnel.

| | | | | | |
|---------------------|-------------|--------|------------------|-------------------|--------|
| GRE | | Status | | | |
| ^ GRE tunnel status | | | | | |
| Index | Description | Status | Local IP Address | Remote IP Address | Uptime |

3.17 Services > Syslog

This section allows you to set the syslog parameters. The system log of the router can be saved in the local, also supports to be sent to remote log server and specified application debugging. By default, the “Log to Remote” option is disabled.

| | |
|-------------------|--|
| Syslog | |
| ^ Syslog Settings | |
| Enable | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Syslog Level | Debug <input type="button" value="v"/> |
| Save Position | RAM <input type="button" value="v"/> <input type="button" value="?"/> |
| Log to Remote | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF <input type="button" value="?"/> |

The window is displayed as below when enabling the “Log to Remote” option.

| | |
|-------------------|--|
| Syslog | |
| ^ Syslog Settings | |
| Enable | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Syslog Level | Debug <input type="button" value="v"/> |
| Save Position | RAM <input type="button" value="v"/> <input type="button" value="?"/> |
| Log to Remote | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF <input type="button" value="?"/> |
| Add Identifier | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF <input type="button" value="?"/> |
| Remote IP Address | <input type="text"/> |
| Remote Port | 514 <input type="text"/> |

| Syslog Settings | | |
|-----------------|--|---------|
| Item | Description | Default |
| Enable | Click the toggle button to enable/disable the Syslog settings option. | OFF |
| Syslog Level | Select from “Debug”, “Info”, “Notice”, “Warning” or “Error”, which from low to high. The lower level will output more syslog in details. | Debug |
| Save Position | Select the save position from “RAM”, “NVM” or “Console”. The data will be cleared after reboot when choose “RAM”. Note: It's not recommended that you save syslog to NVM (Non-Volatile Memory) | RAM |

| | | |
|-------------------|---|------|
| | for a long time. | |
| Log to Remote | Click the toggle button to enable/disable this option. Enable to allow router sending syslog to the remote syslog server. You need to enter the IP and Port of the syslog server. | OFF |
| Add Identifier | Click the toggle button to enable/disable this option. When enabled, you can add serial number to syslog message which used for loading Syslog to RobustLink. | OFF |
| Remote IP Address | Enter the IP address of syslog server when enabling the “Log to Remote” option. | Null |
| Remote Port | Enter the port of syslog server when enabling the “Log to Remote” option. | 514 |

3.18 Services > Event

This section allows you to set the event parameters. Event feature provides an ability to send alerts by SMS or Email when certain system events occur.

Event
Notification
Query

^ General Settings

Signal Quality Threshold ?

| General Settings @ Event | | |
|--------------------------|---|---------|
| Item | Description | Default |
| Signal Quality Threshold | Set the threshold for signal quality. Router will generate a log event when the actual threshold is less than the specified threshold. 0 means disable this option. | 0 |

Event
Notification
Query

^ Event Notification Group Settings

| | | | | | | |
|-------|-------------|----------|------------|------------|-------------|---|
| Index | Description | Send SMS | Send Email | DO Control | Save to NVM | + |
|-------|-------------|----------|------------|------------|-------------|---|

Click + button to add an Event parameters.

Notification

^ General Settings

| | |
|-------------|---|
| Index | <input style="width: 100%;" type="text" value="1"/> |
| Description | <input style="width: 100%;" type="text"/> |
| Send SMS | <input type="checkbox"/> OFF |
| Send Email | <input type="checkbox"/> OFF |
| DO Control | <input type="checkbox"/> OFF |
| Save to NVM | <input type="checkbox"/> OFF ? |

^ Event Selection
?

System Startup OFF

System Reboot OFF

System Time Update OFF

Configuration Change OFF

Cellular Network Type Change OFF

Cellular Data Stats Clear OFF

Cellular Data Traffic Overflow OFF

Poor Signal Quality OFF

Link Switching OFF

WAN Up OFF

WAN Down OFF

WLAN Up OFF

WLAN Down OFF

WWAN Up OFF

WWAN Down OFF

IPSec Connection Up OFF

IPSec Connection Down OFF

OpenVPN Connection Up OFF

OpenVPN Connection Down OFF

LAN Port Link Up OFF

LAN Port Link Down OFF

DDNS Update Success OFF

DDNS Update Fail OFF

Received SMS OFF

SMS Command Execute OFF

| General Settings @ Notification | | |
|---------------------------------|--|---------|
| Item | Description | Default |
| Index | Indicate the ordinal of the list. | -- |
| Description | Enter a description for this group. | Null |
| Sent SMS | Click the toggle button to enable/disable this option. When enabled, the router will send notification to the specified phone numbers via SMS if event occurs. Set the related phone number in "3.21 Services > Email", and use ';' to separate each number. | OFF |
| Send Email | Click the toggle button to enable/disable this option. When enabled, the router will send notification to the specified email box via Email if event occurs. Set the related email address in "3.21 Services > Email". | OFF |

| | | |
|-------------|--|-----|
| DO Control | Click the toggle button to enable / disable this option. After it is turned on, the event router will send it to the corresponding DO in the form of Low / High level. | OFF |
| Save to NVM | Click the toggle button to enable/disable this option. Enable to save event to nonvolatile memory. | OFF |

In the following window you can query various types of events record. Click **Refresh** to query filtered events while click **Clear** to clear the event records in the window.

Event
Notification
Query

^ Event Details

Save Position v

Filtering

```

Sep 11 19:00:53, system startup
Sep 11 19:00:55, LAN port link down, eth0
Sep 11 19:00:55, LAN port link up, eth1
Sep 11 19:01:06, WWAN (cellular) up, WWAN1, ip=10.189.43.25
Sep 11 19:01:16, system time update
Sep 11 19:47:25, configuration change, link_manager restored to default after firmware updating
Sep 11 19:47:25, configuration change, link_manager restored to default after firmware updating
Sep 11 19:47:25, configuration change, link_manager restored to default after firmware updating
Sep 11 19:47:26, configuration change, via web manager
Sep 11 19:47:41, configuration change, link_manager restored to default after firmware updating
Sep 11 19:47:42, configuration change, via web manager
Sep 11 19:47:42, WWAN (cellular) down, WWAN1
Sep 11 19:47:44, WWAN (cellular) up, WWAN1, ip=10.189.43.25
Sep 11 19:48:50, configuration change, via web manager
Sep 11 19:48:51, WWAN (cellular) down, WWAN1
Sep 11 19:48:52, WWAN (cellular) up, WWAN1, ip=10.189.43.25
Sep 11 19:49:04, configuration change, via web manager
Sep 11 19:49:05, WWAN (cellular) down, WWAN1
Sep 11 19:49:10, WLAN up
Sep 11 19:59:33, configuration change, link_manager restored to default after firmware updating
Sep 11 19:59:34, configuration change, via web manager
Sep 11 19:59:36, WLAN down
Sep 11 19:59:36, WWAN (cellular) up, WWAN1, ip=10.189.43.25
Sep 11 20:29:00, LAN port link down, eth1
Sep 11 20:34:06, LAN port link up, eth1
                    
```

Clear
Refresh

| Event Details | | |
|----------------|--|---------|
| Item | Description | Default |
| Save Position | Select the events' save position from "RAM" or "NVM". <ul style="list-style-type: none"> RAM: Random-access memory NVM: Non-Volatile Memory | RAM |
| Filter Message | Enter the filtering message based on the keywords set by users. Click the "Refresh" button, the filtered event will be displayed in the follow box. Use "&" to separate more than one filter message, such as message1&message2. | Null |

3.19 Services > NTP

This section allows you to set the related NTP (Network Time Protocol) parameters, including Time zone, NTP Client and NTP Server.

NTP
Status

^ Timezone Settings

Time Zone

UTC+08:00
v

Expert Setting

?

^ NTP Client Settings

Enable

ON
OFF

Primary NTP Server

pool.ntp.org

Secondary NTP Server

NTP Update Interval

0
?

^ NTP Server Settings

Enable

ON
OFF

| NTP | | |
|----------------------------|---|--------------|
| Item | Description | Default |
| Timezone Settings | | |
| Time Zone | Click the drop down list to select the time zone you are in. | UTC +08:00 |
| Expert Setting | Specify the time zone with Daylight Saving Time in TZ environment variable format. The Time Zone option will be ignored in this case. | Null |
| NTP Client Settings | | |
| Enable | Click the toggle button to enable/disable this option. Enable to synchronize time with the NTP server. | ON |
| Primary NTP Server | Enter primary NTP Server's IP address or domain name. | pool.ntp.org |
| Secondary NTP Server | Enter secondary NTP Server's IP address or domain name. | Null |
| NTP Update interval | Enter the interval (minutes) synchronizing the NTP client time with the NTP server's. Minutes wait for next update, and 0 means update only once. | 0 |
| NTP Server Settings | | |
| Enable | Click the toggle button to enable/disable the NTP server option. | OFF |

This window allows you to view the current time of router and also synchronize the router time. Click Sync button to synchronize the router time with the PC's.

NTP | **Status**

^ Time

System Time 2019-12-31 10:48:42

PC Time 2019-12-31 10:48:44 **Sync**

Last Update Time 2019-12-31 09:52:08

3.20 Services > SMS

This section allows you to set SMS parameters. Router supports SMS management, and user can control and configure their routers by sending SMS. For more details about SMS control, refer to **4.1.2 SMS Remote Control**.

SMS | **SMS Testing**

^ SMS Management Settings ?

Enable **ON** OFF

Authentication Type Password v ?

Phone Number ?

| SMS Management Settings | | |
|-------------------------|---|----------|
| Item | Description | Default |
| Enable | Click the toggle button to enable/disable the SMS Management option. Note: If this option is disabled, the SMS configuration is invalid. | ON |
| Authentication Type | Select Authentication Type from “Password”, “Phonenum” or “Both”. <ul style="list-style-type: none"> • Password: Use the same username and password as WEB manager for authentication. For example, the format of the SMS should be “username: password; cmd1; cmd2; ...” Note: Set the WEB manager password in System > User Management section. • Phonenum: Use the Phone number for authentication, and user should set the Phone Number that is allowed for SMS management. The format of the SMS should be “cmd1; cmd2; ...” • Both: Use both the “Password” and “Phonenum” for authentication. User should set the Phone Number that is allowed for SMS management. The format of the SMS should be “username: password; cmd1; cmd2; ...” | Password |
| Phone Number | Set the phone number used for SMS management, and use ‘;’ to separate each number. Note: It can be null when choose “Password” as the authentication type. | Null |

User can test the current SMS service whether it is available in this section.

SMS
SMS Testing

^ SMS Testing

Phone Number

Message

Result

| SMS Testing | | |
|-------------------------------------|---|---------|
| Item | Description | Default |
| Phone Number | Enter the specified phone number which can receive the SMS from router. | Null |
| Message | Enter the message that router will send it to the specified phone number. | Null |
| Result | The result of the SMS test will be displayed in the result box. | Null |
| <input type="button" value="Send"/> | Click the button to send the test message. | -- |

3.21 Services > Email

Email function supports to send the event notifications to the specified recipient by ways of email.

Email

^ Email Settings

Enable ON OFF

Enable TLS/SSL ON OFF ?

Enable STARTTLS ON OFF

Outgoing Server

Server Port

Timeout ?

Auth Login ON OFF ?

Username

Password

From

Subject

| Email Settings | | |
|-----------------|---|---------|
| Item | Description | Default |
| Enable | Click the toggle button to enable/disable the Email option. | OFF |
| Enable TLS/SSL | Click the toggle button to enable/disable the TLS/SSL option. | OFF |
| Enable STARTTLS | Click the toggle button to enable / disable STARTTLS encryption. | OFF |
| Outgoing server | Enter the SMTP server IP Address or domain name. | Null |
| Server port | Enter the SMTP server port. | 25 |
| Timeout | Set the max time for sending email to SMTP server. When the server doesn't receive the email over this time, it will try to resend. | 10 |
| Auth Login | If the mail server supports AUTH login, you must enable this button and set a username and password. | OFF |
| Username | Enter the username which has been registered from SMTP server. | Null |
| Password | Enter the password of the username above. | Null |
| From | Enter the source address of the email. | Null |
| Subject | Enter the subject of this email. | Null |

3.22 Services > DDNS

This section allows you to set the DDNS parameters. The Dynamic DNS function allows you to alias a dynamic IP address to a static domain name, allows you whose ISP does not assign them a static IP address to use a domain name. This is especially useful for hosting servers via your connection, so that anyone wishing to connect to you may use your domain name, rather than having to use your dynamic IP address, which changes from time to time. This dynamic IP address is the WAN IP address of the router, which is assigned to you by your ISP. The service provider defaults to “DynDNS”, as shown below.

The screenshot shows the 'DDNS Settings' window. At the top, there are two tabs: 'DDNS' and 'Status'. Below the tabs, the 'Enable' toggle is set to 'OFF'. The 'Service Provider' dropdown menu is highlighted with a red box and shows 'DynDNS' selected. Below this, there are input fields for 'Hostname', 'Username', and 'Password', all of which are currently empty.


When “Custom” service provider chosen, the window is displayed as below.

The screenshot shows the 'DDNS Settings' window with the 'Service Provider' dropdown menu highlighted by a red box and set to 'Custom'. Below the dropdown, there is an input field labeled 'URL' which is currently empty. The 'Enable' toggle remains 'OFF'.

DDNS Settings

| Item | Description | Default |
|------------------|---|---------|
| Enable | Click the toggle button to enable/disable the DDNS option. | OFF |
| Service Provider | Select the DDNS service from “DynDNS”, “NO-IP”, “3322” or “Custom”. Note: The DDNS service only can be used after registered by Corresponding service provider. | DynDNS |
| Hostname | Enter the hostname provided by the DDNS server. | Null |
| Username | Enter the username provided by the DDNS server. | Null |
| Password | Enter the password provided by the DDNS server. | Null |
| URL | Enter the URL customized by user. | Null |

Click “Status” bar to view the status of the DDNS.



| DDNS Status | |
|------------------|---|
| Item | Description |
| Status | Display the current status of the DDNS. |
| Last Update Time | Display the date and time for the DDNS was last updated successfully. |

3.23 Services > SSH

Router supports SSH password access and secret-key access.



| SSH Settings | | |
|-------------------------|---|---------|
| Item | Description | Default |
| Enable | Click the toggle button to enable/disable this option. When enabled, you can access the router via SSH. | ON |
| Port | Set the port of the SSH access. | 22 |
| Disable Password Logins | Click the toggle button to enable/disable this option. When enabled, you cannot use username and password to access the router via SSH. In this case, only the key can be used for login. | OFF |

SSH | Keys Management

^ Import Authorized Keys

Authorized Keys No file chosen

| Import Authorized Keys | |
|------------------------|--|
| Item | Description |
| Authorized Keys | Click on "Choose File" to locate an authorized key from your computer, and then click "Import" to import this key into your router. Note: This option is valid when enabling the password logins option. |

3.24 Services > Web Server

This section allows you to modify the parameters of Web Server.

Web Server | Certificate Management

^ General Settings

HTTP Port ?

HTTPS Port ?

| General Settings @ Web Server | | |
|-------------------------------|---|---------|
| Item | Description | Default |
| HTTP Port | Enter the HTTP port number you want to change in router's Web Server. On a Web server, port 80 is the port that the server "listens to" or expects to receive from a Web client. If you configure the router with other HTTP Port number except 80, only adding that port number then you can login router's Web Server. | 80 |
| HTTPS Port | Enter the HTTPS port number you want to change in router's Web Server. On a Web server, port 443 is the port that the server "listens to" or expects to receive from a Web client. If you configure the router with other HTTPS Port number except 443, only adding that port number then you can login router's Web Server. Note: HTTPS is more secure than HTTP. In many cases, clients may be exchanging confidential information with a server, which needs to be secured in order to prevent unauthorized access. For this reason, HTTP was developed by Netscape corporation to allow authorization and secured transactions. | 443 |

This section allows you to import the certificate file into the router.

Web Server | Certificate Management

^ Import Certificate


Import Type v

HTTPS Certificate No file chosen

| Import Certificate | | |
|--------------------|--|---------|
| Item | Description | Default |
| Import Type | Select from "CA" and "Private Key". <ul style="list-style-type: none"> CA: a digital certificate issued by CA center Private Key: a private key file | CA |
| HTTPS Certificate | Click on "Choose File" to locate the certificate file from your computer, and then click "Import" to import this file into your router. | -- |

3.25 Services > Advanced

This section allows you to set the Advanced and parameters.



| System Settings | | |
|-----------------|--|---------|
| Item | Description | Default |
| Device Name | Set the device name to distinguish different devices you have installed; valid characters are a-z, A-Z, 0-9, @, ., -, #, \$, and *. | router |
| User LED Type | Specify the display type of your USR LED. Select from "None", "SIM", "NET", "OpenVPN", "IPSec" or "WiFi". <ul style="list-style-type: none"> None: Meaningless indication, and the LED is off SIM: USR indicator showing the SIM status NET: USR indicator showing the NET status OpenVPN: USR indicator showing the OpenVPN status IPSec: USR indicator showing the IPsec status WiFi: USR indicator showing the WiFi status Note: For more details about USR indicator, see "2.2 LED Indicators". | None |

System
Reboot

^ Periodic Reboot Settings

Periodic Reboot

?

Daily Reboot Time

?

| Periodic Reboot Settings | | |
|--------------------------|--|---------|
| Item | Description | Default |
| Periodic Reboot | Set the reboot period of the router. 0 means disable. | 0 |
| Daily Reboot Time | Set the daily reboot time of the router. You should follow the format as HH:MM, in 24h time frame, otherwise the data will be invalid. Leave it empty means disable. | Null |

3.26 System > Debug

This section allows you to check and download the syslog details.

Syslog

^ Syslog Details

Log Level

v

Filtering

?

```

Sep 11 21:00:58 router user.debug rping[4655]: round-trip min/avg/max = 141.447/141.447/141.447 ms
Sep 11 21:00:58 router user.debug link_manager[3986]: rcv action ping_success from rping
Sep 11 21:00:58 router user.debug link_manager[3986]: target link WWAN1, state Connected
Sep 11 21:00:58 router user.info link_manager[3986]: WWAN1 ping test success
Sep 11 21:05:58 router user.debug link_manager[3986]: WWAN1 (wwan) start ping test
Sep 11 21:05:58 router user.debug rping[4718]: start ping 8.8.8.8 (wwan)
Sep 11 21:05:59 router user.debug rping[4718]: PING 8.8.8.8 (8.8.8.8) from 10.18.11.133: 16 data bytes
Sep 11 21:05:59 router user.debug rping[4718]: 24 bytes from 8.8.8.8: seq=0 ttl=51 time=139.263 ms
Sep 11 21:05:59 router user.debug rping[4718]:
Sep 11 21:05:59 router user.debug rping[4718]: --- 8.8.8.8 ping statistics ---
Sep 11 21:05:59 router user.debug rping[4718]: 1 packets transmitted, 1 packets received, 0% packet loss
Sep 11 21:05:59 router user.debug rping[4718]: round-trip min/avg/max = 139.263/139.263/139.263 ms
Sep 11 21:05:59 router user.debug link_manager[3986]: rcv action ping_success from rping
Sep 11 21:05:59 router user.debug link_manager[3986]: target link WWAN1, state Connected
Sep 11 21:05:59 router user.info link_manager[3986]: WWAN1 ping test success
                    
```

Manual Refresh
v
Clear
Refresh

^ Syslog Files

| Index | File Name | File Size | Modification Time |
|-------|-----------|-----------|--------------------------|
| 1 | messages | 77945 | Wed Sep 11 21:05:59 2019 |

^ System Diagnostic Data

System Diagnostic Data
Generate


| Syslog | | |
|----------------|-------------|---------|
| Item | Description | Default |
| Syslog Details | | |

| | | |
|-------------------------------|---|----------------|
| Log Level | Select from “Debug”, “Info”, “Notice”, “Warn”, “Error” which from low to high. The lower level will output more syslog in detail. | Debug |
| Filtering | Enter the filtering message based on the keywords. Use “&” to separate more than one filter message, such as “keyword1&keyword2”. | Null |
| Refresh | Select from “Manual Refresh”, “5 Seconds”, “10 Seconds”, “20 Seconds” or “30 Seconds”. You can select these intervals to refresh the log information displayed in the follow box. If selecting “manual refresh”, you should click the refresh button to refresh the syslog. | Manual Refresh |
| Clear | Click the button to clear the syslog. | -- |
| Refresh | Click the button to refresh the syslog. | -- |
| Syslog Files | | |
| Syslog Files List | It can show at most 5 syslog files in the list, the files’ name range from message0 to message 4. And the newest syslog file will be placed on the top of the list. | -- |
| System Diagnosing Data | | |
| Generate | Click to generate the syslog diagnosing file. | -- |
| Download | Click to download system diagnosing file. | -- |

3.27 System > Update

This section allows you to upgrade the router system and implement system update by importing and updating firmware files. Import a firmware file from the computer to the router, click **Update** and restart the device as prompted to complete the firmware update.


Note: To access the latest firmware file, please contact your technical support engineer.



3.28 System > App Center

This section allows you to add some required or customized applications to the router. Import and install your applications to the App Center, and reboot the device according to the system prompts. Each installed application will be displayed under the “Services” menu, while other applications related to VPN will be displayed under the “VPN” menu.

Note: After importing the applications to the router, the page display may have a slight delay due to the browser cache. It is recommended that you clear the browser cache first and log in the router again.




The successfully installed app will be displayed in the following list. Click **X** to uninstall the app.



| ^ Installed Apps | | | | |
|------------------|------------------|---------|---------|---------------------------|
| Index | Name | Version | Status | Description |
| 1 | language_chinese | 3.1.0 | Stopped | Chinese language X |

| App Center | | |
|----------------|---|---------|
| Item | Description | Default |
| App Install | | |
| File | Click on “Choose File” to locate the App file from your computer, and then click Install to import this file into your router. Note: File format should be <i>xxx.rpk</i> , e.g. <i>R2000-robustlink-1.0.0.rpk</i> . | -- |
| Installed Apps | | |
| Index | Indicate the ordinal of the list. | -- |
| Name | Show the name of the App. | Null |
| Version | Show the version of the App. | Null |
| Status | Show the status of the App. | Null |
| Description | Show the description for this App. | Null |

3.29 System > Tools

This section provides users three tools: Ping, Traceroute and Sniffer.



| Ping | | |
|---|--|---------|
| Item | Description | Default |
| IP address | Enter the ping's destination IP address or destination domain. | Null |
| Number of Requests | Specify the number of ping requests. | 5 |
| Timeout | Specify the timeout of ping requests. | 1 |
| Local IP | Specify the local IP from cellular WAN, Ethernet WAN or Ethernet LAN. Null stands for selecting local IP address from these three automatically. | Null |
|  | Click this button to start ping request, and the log will be displayed in the follow box. | -- |
|  | Click this button to stop ping request. | -- |

Ping | **Traceroute** | **Sniffer**

^ Traceroute

Trace Address

Trace Hops

Trace Timeout

Start **Stop**

| Traceroute | | |
|---------------|---|---------|
| Item | Description | Default |
| Trace Address | Enter the trace's destination IP address or destination domain. | Null |
| Trace Hops | Specify the max trace hops. Router will stop tracing if the trace hops has met max value no matter the destination has been reached or not. | 30 |
| Trace Timeout | Specify the timeout of Traceroute request. | 1 |
| Start | Click this button to start Traceroute request, and the log will be displayed in the follow box. | -- |
| Stop | Click this button to stop Traceroute request. | -- |

Ping | **Traceroute** | **Sniffer**

^ Sniffer

Interface

Host

Packets Request

Protocol

Status

Start **Stop**

^ Capture Files

| Index | File Name | File Size | Modification Time |
|-------|-----------------------|-----------|--------------------------|
| 1 | 19-09-11_21-18-43.cap | 52420 | Wed Sep 11 21:18:54 2019 |

| Sniffer | | |
|-----------------|---|---------|
| Item | Description | Default |
| Interface | Choose the interface according to your Ethernet configuration. | All |
| Host | Filter the packet that contain the specify IP address. | Null |
| Packets Request | Set the packet number that the router can sniffer at a time. | 1000 |
| Protocol | Select from "All", "IP", "TCP", "UDP" and "ARP". | All |
| Status | Show the current status of sniffer. | -- |
| | Click this button to start the sniffer. | -- |
| | Click this button to stop the sniffer. Once you click this button, a new log file will be displayed in the following List. | -- |
| Capture Files | Every times of sniffer log will be saved automatically as a new file. You can find the file from this Sniffer Traffic Data List and click to download the log, click to delete the log file. It can cache a maximum of 5 files. | -- |

3.30 System > Profile

This section allows you to import or export the configuration file, and restore the router to factory default setting.

Profile
Rollback

^ Import Configuration File

Reset Other Settings to Default ON OFF ?

Ignore Invalid Settings ON OFF ?

XML Configuration File Import

^ Export Configuration File

Ignore Disabled Features ON OFF ?

Add Detailed Information ON OFF ?

Encrypt Secret Data ON OFF ?

XML Configuration File Generate

XML Configuration File Export

^ Default Configuration

Save Running Configuration as Default Save ?

Restore to Default Configuration Restore

| Profile | | |
|----------------------------------|---|---------|
| Item | Description | Default |
| Import Configuration File | | |
| Reset Other Settings to Default | Click the toggle button as "ON" to return other parameters to default settings. | OFF |
| Ignore Invalid Settings | Click the toggle button as "OFF" to ignore invalid settings. | OFF |
| XML Configuration File | Click on <input type="text" value="Choose File"/> to locate the XML configuration file from your computer, and then click Import to import this file into your router. | -- |

| Export Configuration File | | |
|---------------------------------------|--|-----|
| Ignore Disabled Features | Click the toggle button as “OFF” to ignore the disabled features. | OFF |
| Add Detailed Information | Click the toggle button as “On” to add detailed information. | OFF |
| Encrypt Secret Data | Click the toggle button as “ON” to encrypt the secret data. | OFF |
| XML Configuration File | Click Generate button to generate the XML configuration file, and click Export to export the XML configuration file. | -- |
| Default Configuration | | |
| Save Running Configuration as Default | Click Save button to save the current running parameters as default configuration. | -- |
| Restore to Default Configuration | Click Restore button to restore the factory defaults. | -- |

Profile

Rollback

^ Configuration Rollback

Save as a Rollbackable Archive
Save
?

^ Configuration Archive Files

| Index | File Name | File Size | Modification Time | |
|-------|-------------|-----------|--------------------------|---|
| 1 | config1.tgz | 2741 | Sun Jan 1 00:00:05 2017 | ↺ |
| 2 | config2.tgz | 2886 | Sun Jan 1 00:00:05 2017 | ↺ |
| 3 | config3.tgz | 2886 | Sun Jan 1 00:00:05 2017 | ↺ |
| 4 | config4.tgz | 2886 | Thu Dec 26 00:00:02 2019 | ↺ |

| Rollback | | |
|--------------------------------|---|---------|
| Item | Description | Default |
| Configuration Rollback | | |
| Save as a Rollbackable Archive | Create a save point manually. Additionally, the system will create a save point every day automatically if configuration changes. | -- |
| Configuration Archive Files | | |
| Configuration Archive Files | View the related information about configuration archive files, including name, size and modification time. | -- |

3.31 System > User Management

This section allows you to change your username and password, and create or manage user accounts. One router has only one super user who has the highest authority to modify, add and manage other common users.

Note: Your new password must be more than 5 character and less than 32 characters and may contain numbers, upper and lowercase letters, and standard symbols.

Super User

Common User

^ Super User Settings

New Username

?

Old Password

?

New Password

?

Confirm Password

| Super User Settings | | |
|---------------------|---|---------|
| Item | Description | Default |
| New Username | Enter a new username you want to create; valid characters are a-z, A-Z, 0-9, @, ., -, #, \$, and *. | Null |
| Old Password | Enter the old password of your router. The default is "admin". | Null |
| New Password | Enter a new password you want to create; valid characters are a-z, A-Z, 0-9, @, ., -, #, \$, and *. | Null |
| Confirm Password | Enter the new password again to confirm. | Null |

Super User

Common User

^ Common User Settings

Index
Role
Username
+

Click + button to add a new common user. The maximum rule count is 5.

Common User

^ Common Users Settings

Index

Role

v

Username

?

Password

?

| Common User Settings | | |
|----------------------|---|---------|
| Item | Description | Default |
| Index | Indicate the ordinal of the list. | -- |
| Role | Select from "Visitor" and "Editor". <ul style="list-style-type: none"> Visitor: Users only can view the configuration of router under this level | Visitor |

| | | |
|----------|---|------|
| | <ul style="list-style-type: none">• Editor: Users can view and set the configuration of router under this level | |
| Username | Set the Username; valid characters are a-z, A-Z, 0-9, @, ., -, #, \$, and *. | Null |
| Password | Set the password which at least contains 5 characters; valid characters are a-z, A-Z, 0-9, @, ., -, #, \$, and *. | Null |


Chapter 4 Configuration Examples

4.1 Cellular

4.1.1 Cellular Dial-Up

This section shows you how to configure the primary and backup SIM card for Cellular Dial-up. Connect the router correctly and insert two SIM, then open the configuration page. Under the homepage menu, click **Interface > Link Manager > Link Manager > General Settings**, choose “WWAN1” as the primary link and “WWAN2” as the backup link, and set “Cold Backup” as the backup mode, then click “Submit”.

Note: All data will be transferred via WWAN1 when choose WWAN1 as the primary link and set backup mode as cold backup. At the same time, WWAN2 is always offline as a backup link. All data transmission will be switched to WWAN2 when the WWAN1 is disconnected.



Link Manager **Status**

General Settings

Primary Link: WWAN1

Backup Link: WWAN2


Backup Mode: Cold Backup

Revert Interval: 0

Emergency Reboot: ON OFF

Link Settings

| Index | Type | Description | IPv4 Connection Type | IPv6 Connection Type | |
|-------|-------|-------------|----------------------|----------------------|-------------------------------------|
| 1 | WWAN1 | admin | DHCP | SLAAC | <input checked="" type="checkbox"/> |
| 2 | WWAN2 | | DHCP | SLAAC | <input checked="" type="checkbox"/> |
| 3 | WAN | | DHCP | SLAAC | <input checked="" type="checkbox"/> |
| 4 | WLAN | | DHCP | SLAAC | <input checked="" type="checkbox"/> |

Click the  button of WWAN1 to set its parameters according to the current ISP.



Link Manager

General Settings

Index: 1

Type: WWAN1

Description: admin

IPv6 Enable: ON OFF

^ WWAN Settings

Automatic APN Selection ON OFF

Dialup Number

Authentication Type v

PPP Preferred ON OFF ?

Switch SIM By Data Allowance ON OFF ?

Data Allowance ?

Billing Day ?

^ IPv6 LAN Settings

Connection Type v

IPv6 Prefix

IPv6 NAT Enable ON OFF

^ Ping Detection Settings ?

Enable ON OFF

IPv4 Primary Server

IPv4 Secondary Server

IPv6 Primary Server

IPv6 Secondary Server

Interval ?

Retry Interval ?

Timeout ?

Max Ping Tries ?

^ Advanced Settings

IPv4 NAT Enable ON OFF

Upload Bandwidth ?

Download Bandwidth

Overridden Primary DNS

Overridden Secondary DNS

Overridden IPv6 Primary DNS



Overridden IPv6 Secondary DNS

Debug Enable ON OFF

Verbose Debug Enable ON OFF

When finished, click **Submit > Save & Apply** for the configuration to take effect.

The window is displayed below by clicking **Interface > Cellular > Advanced Cellular Settings**.

| Cellular | Status | AT Debug | | | |
|-------------------------------------|----------|--------------|--------------|------------------|---|
| ^ Advanced Cellular Settings | | | | | |
| Index | SIM Card | Phone Number | Network Type | Band Select Type | |
| 1 | SIM1 | | Auto | All |  |
| 2 | SIM2 | | Auto | All |  |

Click the edit button of SIM1 to set its parameters according to your application request.

^ General Settings

Index:
 SIM Card: v
 Phone Number:
 PIN Code: ?
 Extra AT Cmd: ?
 Telnet Port: ?

^ Cellular Network Settings

Network Type: v ?
 Band Select Type: v ?

^ Advanced Settings

Debug Enable: ON OFF
 Verbose Debug Enable: ON OFF

When finished, click **Submit > Save & Apply** for the configuration to take effect.

4.1.2 SMS Remote Control

R2000 supports remote control via SMS. You can use following commands to get the status of the router, and set all the parameters of the router. There are three authentication types for SMS control. You can select from “Password”, “Phonenum” or “Both”.

An SMS command has the following structure:

1. Password mode—Username: **Password;cmd1;cmd2;cmd3; ...cmdn** (available for every phone number).
2. Phonenum mode-- **Password; cmd1; cmd2; cmd3; ... cmdn** (available when the SMS was sent from the phone number which had been added in router’s phone group).
3. Both mode-- **Username: Password;cmd1;cmd2;cmd3; ...cmdn** (available when the SMS was sent from the phone number which had been added in router’s phone group).

SMS command Explanation:

1. User name and Password: Use the same username and password as WEB manager for authentication.

2. **cmd1, cmd2, cmd3 to Cmdn**, the command format is the same as the CLI command, more details about CLI cmd please refer to **Chapter 5 Introductions for CLI**.

Note: Download the configure XML file from the configured web browser. The format of SMS control command can refer to the data of the XML file.

Go to **System > Profile > Export Configuration File**, click **Generate** to generate the XML file and click **Export** to export the XML file.



XML command:

```
<lan >
<network max_entry_num="2" >
<id > 1</id >
<interface > lan0</interface >
<ip > 172.16.10.67</ip >
<netmask > 255.255.0.0</netmask >
<mtu > 1500</mtu >
```

SMS cmd:

```
set lan network 1 interface lan0
set lan network 1 ip 172.16.10.67
set lan network 1 netmask 255.255.0.0
set lan network 1 mtu 1500
```

3. The semicolon character (;) is used to separate more than one commands packed in a single SMS.
4. E.g.

admin:admin;status system

In this command, username is "admin", password is "admin", and the function of the command is to get the system status.

SMS received:

```
hardware_version = 1.0
```

```
firmware_version = "3.0.0"  
kernel_version = 3.10.49  
device_model = R2000  
serial_number = 111111111  
system_uptime = "0 days, 06:17:32"  
system_time = "Thu Jul 6 17:28:51 2017"
```

admin:admin;reboot

In this command, username is "admin", password is "admin", and the command is to reboot the Router.

SMS received:

OK

admin:admin;set firewall remote_ssh_access false;set firewall remote_telnet_access false

In this command, username is "admin", password is "admin", and the command is to disable the remote_ssh and remote_telnet access.

SMS received:

OK

OK

admin:admin; set lan network 1 interface lan0;set lan network 1 ip 172.16.99.11;set lan network 1 netmask 255.255.0.0;set lan network 1 mtu 1500

In this command, username is "admin", password is "admin", and the commands is to configure the LAN parameter.

SMS received:

OK


OK

OK

OK

4.2 Network

4.2.1 IPsec VPN



The configuration of server and client is as follows.

IPsec VPN_Server:

Cisco 2811:

```

Router>enable
Router#config
Configuring from terminal, memory, or network [terminal]?
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#crypto isakmp policy 10
Router(config-isakmp)#?
  authentication  Set authentication method for protection suite
  encryption     Set encryption algorithm for protection suite
  exit           Exit from ISAKMP protection suite configuration mode
  group          Set the Diffie-Hellman group
  hash           Set hash algorithm for protection suite
  lifetime       Set lifetime for ISAKMP security association
  no             Negate a command or set its defaults
Router(config-isakmp)#encryption 3des
Router(config-isakmp)#hash md5
Router(config-isakmp)#authentication pre-share
Router(config-isakmp)#group 2
Router(config-isakmp)#exit
Router(config)#crypto isakmp ?
  client  Set client configuration policy
  enable  Enable ISAKMP
  key     Set pre-shared key for remote peer
  policy  Set policy for an ISAKMP protection suite
Router(config)#crypto isakmp key cisco address 0.0.0.0 0.0.0.0

Router(config)#crypto ?
  dynamic-map  Specify a dynamic crypto map template
  ipsec        Configure IPSEC policy
  isakmp       Configure ISAKMP policy
  key          Long term key operations
  map          Enter a crypto map
Router(config)#crypto ipsec ?
  security-association  Security association parameters
  transform-set         Define transform and settings
Router(config)#crypto ipsec transform-set Trans ?
  ah-md5-hmac  AH-HMAC-MD5 transform
  ah-sha-hmac  AH-HMAC-SHA transform
  esp-3des    ESP transform using 3DES(EDE) cipher (168 bits)
  esp-aes     ESP transform using AES cipher
  esp-des     ESP transform using DES cipher (56 bits)
  esp-md5-hmac  ESP transform using HMAC-MD5 auth
  esp-sha-hmac  ESP transform using HMAC-SHA auth
Router(config)#crypto ipsec transform-set Trans esp-3des esp-md5-hmac

Router(config)#ip access-list extended vpn
Router(config-ext-nacl)#permit ip 10.0.0.0 0.0.0.255 192.168.1.0 0.0.0.255
Router(config-ext-nacl)#exit

Router(config)#crypto map cry-map 10 ipsec-isakmp
% NOTE: This new crypto map will remain disabled until a peer
and a valid access list have been configured.
Router(config-crypto-map)#match address vpn
Router(config-crypto-map)#set transform-set Trans
Router(config-crypto-map)#set peer 202.100.1.1
Router(config-crypto-map)#exit

Router(config)#interface fastEthernet 0/0
Router(config-if)#ip address 58.1.1.1 255.255.255.0
Router(config-if)#cr
Router(config-if)#crypto map cry-map
*Jan 3 07:16:26.785: %CRYPTO-6-ISAKMP_ON_OFF: ISAKMP is ON

```

IPsec VPN_Client:

The window is displayed as below by clicking **VPN > IPsec > Tunnel**.

| General | Tunnel | Status | x509 | | | |
|--------------------------|--------|-------------|---------|--------------|---------------|---|
| ^ Tunnel Settings | | | | | | |
| Index | Enable | Description | Gateway | Local Subnet | Remote Subnet | + |

Click **+** button and set the parameters of IPsec Client as below.

Tunnel

^ General Settings

Index

Enable ON OFF

Description

Gateway ?

Mode v

Protocol v

Local Subnet ?

Remote Subnet ?

Link Binding v ?

^ IKE Settings

IKE Type v

Negotiation Mode v

Encryption Algorithm v

Authentication Algorithm v

IKE DH Group v

Authentication Type v

PSK Secret

Local ID Type v

Remote ID Type v

IKE Lifetime ?

^ SA Settings

Encryption Algorithm v

Authentication Algorithm v

PFS Group v

SA Lifetime ?

DPD Interval ?

DPD Failures ?

Advanced Settings

Enable Compression OFF

Enable Forceencaps OFF ?

Expert Options ?

When finished, click **Submit > Save & Apply** for the configuration to take effect.

The comparison between server and client is as below.

Server (Cisco 2811)

```
Router>enable
Router#config
Configuring from terminal, memory, or network [terminal]?
Enter configuration commands, one per line. End with CTRL/Z.
Router(config)#crypto isakmp policy 10
Router(config-isakmp)#?
  authentication  Set authentication method for protection suite
  encryption     Set encryption algorithm for protection suite
  exit           Exit from ISAKMP protection suite configuration mode
  group          Set the Diffie-Hellman group
  hash           Set hash algorithm for protection suite
  lifetime       Set lifetime for ISAKMP security association
  no             Negates a command or set its defaults
Router(config-isakmp)#encryption 3des
Router(config-isakmp)#hash md5
Router(config-isakmp)#authentication pre-share
Router(config-isakmp)#group 2
Router(config-isakmp)#exit
Router(config)#crypto isakmp ?
  client  Set client configuration policy
  enable  Enable ISAKMP
  key     Set pre-shared key for remote peer
  policy  Set policy for an ISAKMP protection suite
Router(config)#crypto isakmp key cisco address 0.0.0.0 0.0.0.0

Router(config)#crypto ?
  dynamic-map  Specify a dynamic crypto map template
  ipsec        Configure IPSEC policy
  isakmp       Configure ISAKMP policy
  key          Long term key operations
  map          Enter a crypto map
Router(config)#crypto ipsec ?
  security-association  Security association parameters
  transform-set         Define transform and settings
Router(config)#crypto ipsec transform-set Trans ?
  ah-md5-hmac  AH-IPSEC-MD5 transform
  ah-sha-hmac  AH-IPSEC-SHA transform
  esp-3des    ESP transform using 3DES(EDE) cipher (168 bits)
  esp-aes     ESP transform using AES cipher
  esp-des     ESP transform using DES cipher (64 bits)
  esp-md5-hmac ESP transform using HMAC-MD5 auth
  esp-sha-hmac ESP transform using HMAC-SHA auth
Router(config)#crypto ipsec transform-set Trans esp-3des esp-md5-hmac

Router(config)#ip access-list extended vpn
Router(config-ext-nacl)#permit ip 10.0.0.0 0.0.0.255 192.168.1.0 0.0.0.255
Router(config-ext-nacl)#exit

Router(config)#crypto map cry-map 10 ipsec-isakmp
% NOTE: This new crypto map will remain disabled until a peer
and a valid access list have been configured.
Router(config-crypto-map)#match address vpn
Router(config-crypto-map)#set transform-set Trans
Router(config-crypto-map)#set peer 202.100.1.1
Router(config-crypto-map)#exit

Router(config)#interface FastEthernet 0/0
Router(config-if)#ip address 58.1.1.1 255.255.255.0
Router(config-if)#no
Router(config-if)#crypto map cry-map
*Jan  3 07:16:26.785: %CRYPTO-6-ISAKMP_ON_OFF: ISAKMP is ON
```

General Settings

Index: 1

Enable: ON

Description:

Gateway: 58.1.1.1 ?

Mode: Tunnel v

Protocol: ESP v

Local Subnet: 192.168.1.0/24 ?

Remote Subnet: 0.0.0.0/24 ?

Link Binding: Unspecified v ?

IKE Settings

IKE Type: IKEv1 v

Negotiation Mode: Main v

Encryption Algorithm: 3DES v

Authentication Algorithm: MD5 v

IKE DH Group: DHgroup2 v

Authentication Type: PSK v

PSK Secret: *****

Local ID Type: Default v

Remote ID Type: Default v

IKE Lifetime: 86400 ?

SA Settings

Encryption Algorithm: 3DES v

Authentication Algorithm: MD5 v

PFS Group: DHgroup2 v

SA Lifetime: 28800 ?

DPD Interval: 30 ?

DPD Failures: 150 ?

Advanced Settings

Enable Compression: OFF

Enable Forceencaps: OFF ?


Expert Options: ?

Annotations:

- Red box around Cisco configuration lines: Router(config-isakmp)#encryption 3des, Router(config-isakmp)#hash md5, Router(config-isakmp)#authentication pre-share, Router(config-isakmp)#group 2, Router(config-isakmp)#exit, Router(config)#crypto isakmp ?
- Red box around Cisco configuration lines: Router(config)#crypto ipsec transform-set Trans esp-3des esp-md5-hmac
- Red arrow pointing from Cisco configuration to GUI: Router IKE Settings should be consistent with service fees.
- Red arrow pointing from Cisco configuration to GUI: Router SA Settings should be consistent with service fees.

4.2.2 OpenVPN

OpenVPN supports two modes, including Client and P2P. Here takes Client as an example.



OpenVPN_Server:

Generate relevant OpenVPN certificate on the server side firstly, and refer to the following commands to configuration the Server:

```
local 202.96.1.100
mode server
port 1194
proto udp
dev tun
tun-mtu 1500
fragment 1500
ca ca.crt
cert Server01.crt
key Server01.key
dh dh1024.pem
server 10.8.0.0 255.255.255.0
ifconfig-pool-persist ipp.txt
push "route 192.168.3.0 255.255.255.0"
client-config-dir ccd
route 192.168.1.0 255.255.255.0
keepalive 10 120
cipher BF-CBC
comp-lzo
max-clients 100
persist-key
persist-tun
status openvpn-status.log
verb 3
```

Note: For more configuration details, please contact your technical support engineer.

OpenVPN_Client:

Click **VPN > OpenVPN > OpenVPN** as below.

Click **+** to configure the Client01 as below.

OpenVPN

General Settings

- Index: 1
- Enable: **ON** OFF
- Description: client01
- Mode: Client ?
- Protocol: UDP
- Peer Address: 202.96.1.100
- Peer Port: 1194
- Interface Type: TUN
- Authentication Type: X509CA ?
- Encrypt Algorithm: BF
- Authentication Algorithm: SHA1
- Renegotiation Interval: 86400 ?
- Keepalive Interval: 20 ?
- Keepalive Timeout: 120 ?
- TUN MTU: 1500
- Max Frame Size: 1400
- Private Key Password: •••••
- Enable Compression: **ON** OFF
- Enable NAT: ON **OFF**
- Enable DNS overrid: ON **OFF** ?
- Verbose Level: 3 ?

^ Advanced Settings

Enable HMAC Firewall OFF


Enable PKCS#12 OFF

Enable nsCertType OFF

Expert Options ?

When finished, click **Submit > Save & Apply** for the configuration to take effect.

4.2.3 GRE VPN



The configuration of two points is as follows.

The window is displayed as below by clicking **VPN > GRE > GRE**.

| GRE | Status | | | |
|--------------------------|--------|-------------|-------------------|--|
| ^ Tunnel Settings | | | | |
| Index | Enable | Description | Remote IP Address | |

GRE-1:

Click **+** button and set the parameters of GRE-1 as below.

^ Tunnel Settings

| | |
|-------------------------------------|---|
| Index | <input type="text" value="1"/> |
| Enable | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Description | <input type="text"/> |
| Remote IP Address | <input type="text" value="59.1.1.1"/> |
| Local Virtual IP Address | <input type="text" value="10.8.0.1"/> |
| Local Virtual Netmask/Prefix Length | <input type="text" value="255.255.255.0"/> ? |
| Remote Virtual IP Address | <input type="text" value="10.8.0.2"/> |
| Enable Default Route | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Enable NAT | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Secrets | <input type="password" value="*****"/> |
| Link Binding | <input type="text" value="Unspecified"/> v ? |

When finished, click **Submit > Save & Apply** for the configuration to take effect.

GRE-2:

Click **+** button and set the parameters of GRE-1 as below.

GRE

^ Tunnel Settings

| | |
|-------------------------------------|---|
| Index | <input type="text" value="1"/> |
| Enable | <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF |
| Description | <input type="text" value="GRE-2"/> |
| Remote IP Address | <input type="text" value="58.1.1.1"/> |
| Local Virtual IP Address | <input type="text" value="10.8.0.2"/> |
| Local Virtual Netmask/Prefix Length | <input type="text" value="255.255.255.0"/> ? |
| Remote Virtual IP Address | <input type="text" value="10.8.0.1"/> |
| Enable Default Route | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Enable NAT | <input type="checkbox"/> ON <input checked="" type="checkbox"/> OFF |
| Secrets | <input type="password" value="*****"/> |
| Link Binding | <input type="text" value="Unspecified"/> v ? |

When finished, click **Submit > Save & Apply** for the configuration to take effect.

The comparison between GRE-1 and GRE-2 is as below.

GRE Tunnel Settings (Left):

- Index: 1
- Enable: ON
- Description: GRE-1
- Remote IP Address: 58.1.1.1
- Local Virtual IP Address: 10.8.0.1
- Local Virtual Netmask/Prefix Length: 255.255.255.0
- Remote Virtual IP Address: 10.8.0.2
- Enable Default Route: OFF
- Enable NAT: OFF
- Secrets: *****
- Link Binding: Unspecified


GRE Tunnel Settings (Right):

- Index: 1
- Enable: ON
- Description: GRE-2
- Remote IP Address: 59.1.1.1
- Local Virtual IP Address: 10.8.0.2
- Local Virtual Netmask/Prefix Length: 255.255.255.0
- Remote Virtual IP Address: 10.8.0.1
- Enable Default Route: OFF
- Enable NAT: OFF
- Secrets: *****
- Link Binding: Unspecified

Chapter 5 Introductions for CLI

5.1 What Is CLI

Command-line interface (CLI) is a software interface providing another way to set the parameters of equipment from the [SSH](#) or through a [telnet](#) network connection.



```

New Session - Xshell 5 (Free for Home/School)
File Edit View Tools Tab Window Help
telnet://192.168.0.1:23
To add the current session, click on the left arrow button.
1 New Session
router login: admin
Password:
#
!           Comments
add         Add a list entry of configuration
clear       Clear statistics
config      Configuration operation
debug       Output debug information to the console
del         Delete a list entry of configuration
do          Set the level state of the do
exit        Exit from the CLI
help        Display an overview of the CLI syntax
ovpn_cert_get Download OpenVPN certificate file via http or ftp
ping        Send messages to network hosts
reboot      Halt and perform a cold restart
set         Set system configuration
show        Show system configuration
status      Show running system information
tftpupdate  Update firmware or configuration file using tftp
traceroute  Print the route packets trace to network host
urlupdate   Update firmware via http or ftp
ver         Show version of firmware
#
Send text to the current tab only
telnet://192.168.0.1:23  TELNET  xterm  94x25  38,3  1 session  CAP NUM

```

Route login:

Router login: admin

Password: admin

#

CLI commands:

? (Note: the '?' won't display on the page.)

| | |
|--------|---|
| ! | Comments |
| add | Add a list entry of configuration |
| clear | Clear statistics |
| config | Configuration operation |
| debug | Output debug information to the console |
| del | Delete a list entry of configuration |
| exit | Exit from the CLI |

| | |
|---------------|---|
| help | Display an overview of the CLI syntax |
| ovpn_cert_get | Download OpenVPN certificate file via http or ftp |
| ping | Send messages to network hosts |
| reboot | Halt and perform a cold restart |
| route | Static route modify dynamically, this setting will not be saved |
| set | Set system configuration |
| show | Show system configuration |
| status | Show running system information |
| tftpupdate | Update firmware using tftp |
| traceroute | Print the route packets trace to network host |
| urlupdate | Update firmware using http or ftp |
| ver | Show version of firmware |

5.2 How to Configure the CLI

Following is a table about the description of help and the error should be encountered in the configuring program.

| Commands /tips | Description |
|--|--|
| ? | Typing a question mark “?” will show you the help information. eg. # config (Press ‘?’) config Configuration operation # config (Press spacebar +’?’) commit Save the configuration changes and take effect changed configuration save_and_apply Save the configuration changes and take effect changed configuration loaddefault Restore Factory Configuration |
| Ctrl+c | Press these two keys at the same time, except its “copy” function but also can be used for “break” out of the setting program. |
| Syntax error: The command is not completed | Command is not completed. |
| Tick space key+ Tab key | It can help you finish you command. Example: # config (tick enter key) Syntax error: The command is not completed # config (tick space key+ Tab key) commit save_and_apply loaddefault |
| #config commit | When your setting finished, you should enter those commands to make |

| | |
|-------------------------|--|
| # config save_and_apply | your setting take effect on the device. Note: Commit and save_and_apply plays the same role. |
|-------------------------|--|

5.3 Commands Reference

| Commands | Syntax | Description |
|----------|-------------------------|---|
| Debug | Debug <i>parameters</i> | Turn on or turn off debug function |
| Show | Show <i>parameters</i> | Show current configuration of each function , if we need to see all please using “show running ” |
| Set | Set <i>parameters</i> | All the function parameters are set by commands set and add, the difference is that set is for the single parameter and add is for the list parameter |
| Add | Add <i>parameters</i> | |

Note: Download the config.XML file from the configured web browser. The command format can refer to the config.XML file format.

5.4 Quick Start with Configuration Examples

The best and quickest way to master CLI is firstly to view all features from the webpage and then read all CLI commands at a time, finally learn to configure it with some reference examples.

Example 1: Show current version

```
# status system
hardware_version = 1.0
firmware_version = "3.0.0"
kernel_version = 3.10.49
device_model = R2000
serial_number = 111111111
system_uptime = "0 days, 06:17:32"
system_time = "Thu Jul 6 17:28:51 2017"
```

Example 2: Update firmware via tftp

```
# tftpupdate (space+?)
firmware New firmware
# tftpupdate firmware (space+?)
String Firmware name
# tftpupdate firmware filename R2000-firmware-sysupgrade-unknown.bin host 192.168.100.99 //enter a new
firmware name
Downloading
R2000-firmware-s 100% |*****| 5018k 0:00:00 ETA
```

```

Flashing
Checking 100%
Decrypting 100%
Flashing 100%
Verifying 100%
Verify Success
upgrade success //update success
# config save_and_apply
OK // save and apply current configuration, make you configuration effect

```

Example 3: Set link-manager

```

# set
# set
  at_over_telnet    AT Over Telnet
  cellular          Cellular
  ddns             Dynamic DNS
  ethernet         Ethernet
  event            Event Management
  firewall         Firewall
  gre              GRE
  ipsec           IPsec
  lan              Local Area Network
  link_manager     Link Manager
  ntp              NTP
  openvpn          OpenVPN
  reboot           Automatic Reboot
  RobustLink      RobustLink
  route            Route
  sms              SMS
  snmp             SNMP agent
  ssh              SSH
  syslog           Syslog
  system           System
  user_management  User Management
  vrrp             VRRP
  web_server       Web Server
# set link_manager
  primary_link     Primary Link
  backup_link      Backup Link
  backup_mode      Backup Mode
  emergency_reboot Emergency Reboot
  link             Link Settings
# set link_manager primary_link (space+?)
Enum Primary Link (wwan1/wwan2/wan)
# set link_manager primary_link wwan1 //select "wwan1" as primary_link

```

```

OK //setting succeed
# set link_manager link 1
  type          Type
  desc          Description
  connection_type Connection Type
  wwan          WWAN Settings
  static_addr   Static Address Settings
  pppoe         PPPoE Settings
  ping         Ping Settings
  mtu           MTU
  dns1_overridden Overridden Primary DNS
  dns2_overridden Overridden Secondary DNS
# set link_manager link 1 type wwan1
OK
# set link_manager link 1 wwan
  auto_apn          Automatic APN Selection
  apn              APN
  username         Username
  password         Password
  dialup_number    Dialup Number
  auth_type        Authentication Type
  aggressive_reset Aggressive Reset
  switch_by_data_allowance Switch SIM By Data Allowance
  data_allowance   Data Allowance
  billing_day      Billing Day
# set link_manager link 1 wwan switch_by_data_allowance true
OK
#
# set link_manager link 1 wwan data_allowance 100 //open cellular switch_by_data_traffic
OK //setting succeed
# set link_manager link 1 wwan billing_day 1 //setting specifies the day of month for billing
OK // setting succeed
...
# config save_and_apply
OK // save and apply current configuration, make you configuration effect

```

Example 4: Set Ethernet

```

# set Ethernet port_setting 2 port_assignmEnt lan0 //Set Table 2 (eth1) to lan0
OK
# config save_and_apply //setting succeed
OK

```

Example 5: Set LAN IP address

```
# show lan all
network {
    id = 1
    interface = lan0
    ip = 192.168.0.1
    netmask = 255.255.255.0
    mtu = 1500
    dhcp {
        enable = true
        mode = server
        relay_server = ""
        pool_start = 192.168.0.2
        pool_end = 192.168.0.100
        netmask = 255.255.255.0
        gateway = ""
        primary_dns = ""
        secondary_dns = ""
        wins_server = ""
        lease_time = 120
        expert_options = ""
        debug_enable = false
    }
}
multi_ip {
    id = 1
    interface = lan0
    ip = 172.16.10.67
    netmask = 255.255.0.0
}
#
# set lan
network      Network Settings
multi_ip    Multiple IP Address Settings
vlan        VLAN
# set lan network 1(space+?)
interface    Interface
ip           IP Address
netmask     Netmask
mtu         MTU
dhcp        DHCP Settings
# set lan network 1 interface lan0
OK
# set lan network 1 ip 172.16.10.67           //set IP address for lan
OK                                           //setting succeed
```

```
# set lan network 1 netmask 255.255.0.0
OK
#
...
# config save_and_apply
OK // save and apply current configuration, make you configuration effect
```

Example 6: CLI for setting Cellular

```
# show cellular all
sim {
    id = 1
    card = sim1
    phone_number = ""
    extra_at_cmd = ""
    network_type = auto
    band_select_type = all
    band_gsm_850 = false
    band_gsm_900 = false
    band_gsm_1800 = false
    band_gsm_1900 = false
    band_wcdma_850 = false
    band_wcdma_900 = false
    band_wcdma_1900 = false
    band_wcdma_2100 = false
    band_lte_800 = false
    band_lte_850 = false
    band_lte_900 = false
    band_lte_1800 = false
    band_lte_1900 = false
    band_lte_2100 = false
    band_lte_2600 = false
    band_lte_1700 = false
    band_lte_700 = false
    band_tdd_lte_2600 = false
    band_tdd_lte_1900 = false
    band_tdd_lte_2300 = false
    band_tdd_lte_2500 = false
}
sim {
    id = 2
    card = sim2
    phone_number = ""
    extra_at_cmd = ""
    network_type = auto
    band_select_type = all
    band_gsm_850 = false
```

```

band_gsm_900 = false
band_gsm_1800 = false
band_gsm_1900 = false
band_wcdma_850 = false
band_wcdma_900 = false
band_wcdma_1900 = false
band_wcdma_2100 = false
band_lte_800 = false
band_lte_850 = false
band_lte_900 = false
band_lte_1800 = false
band_lte_1900 = false
band_lte_2100 = false
band_lte_2600 = false
band_lte_1700 = false
band_lte_700 = false
band_tdd_lte_2600 = false
band_tdd_lte_1900 = false
band_tdd_lte_2300 = false
band_tdd_lte_2500 = false
}
# set(space+?)
at_over_telnet    cellular        ddns            dhcp            dns
event            firewall        ipsec           lan             link_manager
ntp              openvpn        reboot          route           serial_port
sms              snmp           syslog          system          user_management
vrrp
# set cellular(space+?)
  sim    SIM Settings
# set cellular sim(space+?)
  Integer  Index (1..2)

# set cellular sim 1(space+?)
  card                SIM Card
  phone_number        Phone Number
  extra_at_cmd        Extra AT Cmd
  network_type        Network Type
  band_select_type    Band Select Type
  band_gsm_850        GSM 850
  band_gsm_900        GSM 900
  band_gsm_1800       GSM 1800
  band_gsm_1900       GSM 1900
  band_wcdma_850      WCDMA 850
  band_wcdma_900      WCDMA 900
  band_wcdma_1900     WCDMA 1900
  band_wcdma_2100     WCDMA 2100

```

```
band_lte_800      LTE 800 (band 20)
band_lte_850      LTE 850 (band 5)
band_lte_900      LTE 900 (band 8)
band_lte_1800     LTE 1800 (band 3)
band_lte_1900     LTE 1900 (band 2)
band_lte_2100     LTE 2100 (band 1)
band_lte_2600     LTE 2600 (band 7)
band_lte_1700     LTE 1700 (band 4)
band_lte_700      LTE 700 (band 17)
band_tdd_lte_2600 TDD LTE 2600 (band 38)
band_tdd_lte_1900 TDD LTE 1900 (band 39)
band_tdd_lte_2300 TDD LTE 2300 (band 40)
band_tdd_lte_2500 TDD LTE 2500 (band 41)
# set cellular sim 1 phone_number 18620435279
OK
...
# config save_and_apply
OK                                     // save and apply current configuration, make you configuration effect
```

Glossary

| Abbr. | Description |
|----------|--|
| AC | Alternating Current |
| APN | Access Point Name |
| ASCII | American Standard Code for Information Interchange |
| CE | Conformité Européene (European Conformity) |
| CHAP | Challenge Handshake Authentication Protocol |
| CLI | Command Line Interface for batch scripting |
| CSD | Circuit Switched Data |
| CTS | Clear to Send |
| dB | Decibel |
| dBi | Decibel Relative to an Isotropic radiator |
| DC | Direct Current |
| DCD | Data Carrier Detect |
| DCE | Data Communication Equipment (typically modems) |
| DCS 1800 | Digital Cellular System, also referred to as PCN |
| DI | Digital Input |
| DO | Digital Output |
| DSR | Data Set Ready |
| DTE | Data Terminal Equipment |
| DTMF | Dual Tone Multi-frequency |
| DTR | Data Terminal Ready |
| EDGE | Enhanced Data rates for Global Evolution of GSM and IS-136 |
| EMC | Electromagnetic Compatibility |
| EMI | Electro-Magnetic Interference |
| ESD | Electrostatic Discharges |
| ETSI | European Telecommunications Standards Institute |
| EVDO | Evolution-Data Optimized |
| FDD LTE | Frequency Division Duplexing Long Term Evolution |
| GND | Ground |
| GPRS | General Packet Radio Service |
| GRE | generic route encapsulation |
| GSM | Global System for Mobile Communications |
| HSPA | High Speed Packet Access |
| ID | identification data |
| IMEI | International Mobile Equipment Identity |
| IP | Internet Protocol |
| IPsec | Internet Protocol Security |
| kbps | kbits per second |
| L2TP | Layer 2 Tunneling Protocol |

| Abbr. | Description |
|--------------|---|
| LAN | local area network |
| LED | Light Emitting Diode |
| M2M | Machine to Machine |
| MAX | Maximum |
| Min | Minimum |
| MO | Mobile Originated |
| MS | Mobile Station |
| MT | Mobile Terminated |
| OpenVPN | Open Virtual Private Network |
| PAP | Password Authentication Protocol |
| PC | Personal Computer |
| PCN | Personal Communications Network, also referred to as DCS 1800 |
| PCS | Personal Communication System, also referred to as GSM 1900 |
| PDU | Protocol Data Unit |
| PIN | Personal Identity Number |
| PLCs | Program Logic Control System |
| PPP | Point-to-point Protocol |
| PPTP | Point to Point Tunneling Protocol |
| PSU | Power Supply Unit |
| PUK | Personal Unblocking Key |
| R&TTE | Radio and Telecommunication Terminal Equipment |
| RF | Radio Frequency |
| RTC | Real Time Clock |
| RTS | Request to Send |
| RTU | Remote Terminal Unit |
| Rx | Receive Direction |
| SDK | Software Development Kit |
| SIM | subscriber identification module |
| SMA antenna | Stubby antenna or Magnet antenna |
| SMS | Short Message Service |
| SNMP | Simple Network Management Protocol |
| TCP/IP | Transmission Control Protocol / Internet Protocol |
| TE | Terminal Equipment, also referred to as DTE |
| Tx | Transmit Direction |
| UART | Universal Asynchronous Receiver-transmitter |
| UMTS | Universal Mobile Telecommunications System |
| USB | Universal Serial Bus |
| USSD | Unstructured Supplementary Service Data |
| VDC | Volts Direct current |
| VLAN | Virtual Local Area Network |
| VPN | Virtual Private Network |
| VSWR | Voltage Stationary Wave Ratio |

| Abbr. | Description |
|-------|-------------------|
| WAN | Wide Area Network |

Guangzhou Robustel Co., Ltd.

Add: 501, Building 2, No. 63, Yong'an Avenue,
Huangpu District, Guangzhou, China 510660

Tel: 86-20-82321505

Email: support@robustel.com

Web: www.robustel.com